







































































Original	Substitut	Original	Substitut
	Power		Power
	Open/Close		Eject / Surround
	Disc/Pop Up Menu		Shift + Menu /
	Radio		TV/Radio /
	Audio Source		AV / Input / RDS
	USB		Shift + 8
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Home		Menu / Home
	Top Menu		D.Menu / Top
	Options		Setup / OPT /
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	Info		Info / Angle
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	<<		<< / Tune-
	Stop		Stop / Hold
	>>		>> / Tune+
	I<		I<< / Preset-
	>I		>>I / Preset+
	Mute		Mute / Dimmer
	Vol+		Vol+
	Surr. Sound		Shift + Eject / Surround
	Treble		Zoom / Size
	Vol-		Vol-
	Sound Mode		Sound / Title
	Bass		Picture / Format



