



Original	Substitut	Original	Substitut
	TV/PC		Eject / Surround
	Power		Power
	Input		AV / Input / RDS
	TV/Radio		TV/Radio /
	Text		Text / Goto
	I-II		Audio / Lang I/II
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	List		Smart / List

Original	Substitut	Original	Substitut
	0		0
	Q.View		Display / Media
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Info		Info / Angle
	Down		Down
	Guide		Guide / EPG / -/-
	Vol+		Vol+
	Return		Back / Return
	PR+		CH+ / Page+
	Vol-		Vol-
	PR-		CH- / Page-
	FAV		Fav / Marker / PC



