























































































Original	Substitut	Original	Substitut
	Power		Power
	O		Guide
	Rec		Rec
	I<<		I<<
	Red		Red
	Green/[[]]		Green
	Stop		Stop
	Play		Play
	Yellow / List		Yellow
	>>I		>>I
	PIP [■]		Blue
	AV/[?]		AV
	I-II/[≡≡]		Dual
	[<>]/[+]		Format
	[-O-]		Exit
	Menu		Menu
	[≡]		Text
	Pause		Pause
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Smart J		Smart
	Smart []		Media
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
































Original	Substitut
	Power
	O
	Rec
	I<<
	Red
	Green/[[]]
	Stop
	Play
	Yellow / List
	PIP [■]
	>>I
	AV/[?]
	I-II/[≡≡]
	[<>]/[+]
	-O-
	Menu
	Pause

Original	Substitut
	[≡]
	Up
	Left
	OK
	Right
	Down
	Vol +
	Vol -
	Mute
	Smart ♪
	Smart []
	P+
	P-
	1
	2
	3
	4





Original	Substitut	Original	Substitut
	Power		Power
	I<<		I<<
	>>I		>>I
	AV/[?]		AV
	I-II[≡ ≡]		Dual
	[<>]/[+]		Format
	-O-		Exit
	Pause		Pause
	[≡]		Text
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute

Original	Substitut	Original	Substitut
	Smart J		Smart
	Smart []		Media
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Pre Ch

