







































































Original		Substitut		Original		Substitut	
	Power DVD		Power		A-B/Repeat		Options
	Display		Info		Clear		Exit
	SYS Video		Back		FTS/Program		Sleep
	On/Off PBC		Media		Menu System		Menu
	1		1		Menu Disc		D. Menu
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		OK		Ok
	7		7		Stop/Return		Stop
	8		8		Play		Play
	9		9		Pause		Pause
	0		0		>>		>>
	+10		Guide		<<		<<
	Title		Pre Ch		>		>>
	Repeat		Text		<		<<





	Original		Substitut
	FWD Slow		Ch +
	REV Slow		Ch -
	Subtitle		Subt
	Angle		Format
	Zoom		Eject
	Audio		Dual
	Search		TV/R
	Preview		Green
	Mode Sound		Yellow
	3D Sound		3D
	Power Speakers		Shift + Power
	1-2-3 Input		AV
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Bass+		Shift + Up
	Bass-		Shift + Down

	Original		Substitut
	Treble+		Shift + Ch +
	Treble-		Shift + Ch -

