














































































Original	Substitut	Original	Substitut
	Power		Power
	Eject		Shift + Eject
	Open/Close		Eject
	Display Call		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	Channel+		Ch +
	Channel-		Ch -
	Showview/Progra		Guide

Original	Substitut	Original	Substitut
	Timer Rec		AV
	Rec OTR		Rec
	Marker/Tape		Options
	Jump/Zero Return		Pre Ch
	Clock/Counter		Yellow
	Counter Reset		Green
	Tv/VCR		TV/R
	VCR		Smart
	DVD		Media
	Setup Menu		Menu
	DVD Menu		D. Menu
	Up		Up
	Down		Down
	Right/TRK+		Right
	Left/TRK-		Left
	Enter/Select		Ok
	Title		Red





Original		Substitut		Original		Substitut	
	Return		Back				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	I<</- Index/Skip		I<<				
	<<		<<				
	>>		>>				
	>>I/Skip/Index +		>>I				
	I>/Slow		Blue				
	Cancel		Exit				
	Repeat A-B		Text				
	Zoom		3D				
	Angle		List				
	Play Mode		Shift + Play				
	Subtitle		Subt				
	Audio		Dual				

