






































Original	Substitut	Original	Substitut
	Power		Power
	Open/Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	10+		Guide
	Video Out		AV
	<<		<<
	>>		>>
	Pause		Pause

Original	Substitut	Original	Substitut
	Stop		Stop
	Play		Play
	I<<		I<<
	>>I		>>I
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu DVD		Menu
	Setup		Options
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Language		Dual
	Angle		TV/R
	Subtitle		Subt





Original		Substitut		Original	Substitut
	Progressive Scan		Format		
	Repeat		Text		
	Random		3D		
	Zoom		Shift + Eject		
	OSD		Pre Ch		
	A-B		List		
	PBC		Back		
	L/R		Info		
	Program		Sleep		
	Sub-Menu		D. Menu		

