



































































Original	Substitut	Original	Substitut
Source	AV / Input / RDS	>10	Guide / EPG / -/--
Power	Power	0/10	0
DVD	Red / Netflix / Search	C	Exit / Cancel / Clear
TUN	Green / APP / Repeat	Tv Vol+	Shift + Vol+
V1	Blue / Prime Video / Random	Tv Vol-	Shift + Vol-
V2	Shift + Blue / Prime	Up/FQ+	Up
A1	Yellow / YouTube / Repeat	Up/FQ+	>> / Tune+
A2	Shift + Red / Netflix /	Left/ST-	Left
1	1	Left/ST-	I<< / Preset-
2	2	Right/ST+	Right
3	3	Right/ST+	>>I / Preset+
4	4	Down/FQ-	Down
5	5	Down/FQ-	<< / Tune-
6	6	Band	Display / Media
7	7	Station Memory	Smart / List
8	8	Mono	Audio / Lang I/II
9	9	1 Tv	Shift + 1









































































Original	Substitut	Original	Substitut
 2 Tv	 Shift + 2	 Menu Tv	 Shift + Menu /
 3 Tv	 Shift + 3	 Stop Tv	 Shift + Stop /
 4 Tv	 Shift + 4	 Play Tv	 Shift + Play /
 5 Tv	 Shift + 5	 Pause Tv	 Shift + Pause / Step /
 6 Tv	 Shift + 6	 Rec Tv	 Shift + Rec / Rec Mode
 7 Tv	 Shift + 7	 I<< Tv	 Shift + I<< / Preset-
 8 Tv	 Shift + 8	 >>I Tv	 Shift + >>I / Preset+
 9 Tv	 Shift + 9	 CH- Tv	 Shift + CH- /
 >10 Tv	 Shift + Guide / EPG / -/-	 CH+ Tv	 Shift + CH+ /
 0/10 Tv	 Shift + 0	 << Tv	 Shift + << /
 C Tv	 Shift + Exit / Cancel / Clear	 >> Tv	 Shift + >> /
 Power Tv	 Shift + Power	 PGM Tv	 Shift + D.Menu / Top Menu
 Up Tv	 Shift + Up	 RDM Tv	 Shift + Subtitle / EQ
 Left Tv	 Shift + Left	 Disp Tv	 Shift + Display / Media
 Enter Tv	 Shift + OK	 Last Memory Tv	 Shift + Back / Return
 Right Tv	 Shift + Right		
 Down Tv	 Shift + Down		









































































Original		Substitut		Original		Substitut	
	Source		AV / Input / RDS		Sleep		Sleep / Timer
	Power		Power		6		6
	DVD		Green / APP / Repeat		Time/Clock ADJ		Shift + Sleep / Timer
	TUN		Red / Netflix / Search		7		7
	V1		Blue / Prime Video / Random		[I]/DTS		Picture / Format
	V2		Shift + Blue / Prime		8		8
	A1		Yellow / YouTube / Repeat		Test Tone		Text / Goto
	A2		Shift + Red / Netflix /		9		9
	1		1		CH Select		Shift + Smart / List
	Midnight		Zoom / Size		>10		Guide / EPG / -/--
	2		2		Sound Control		Sound / Title
	P.Bass		Eject / Surround		0/10		0
	3		3		DSP		Setup / OPT /
	Function		Smart / List		C		Fav / Marker / PC
	4		4		Enter/Disc / DSP		Shift + OK
	FL Dimmer		Shift + Mute / Dimmer		TV CH+		Shift + CH+ /
	5		5		Tv Vol+		Shift + Vol+









































































Original	Substitut	Original	Substitut
 System	 Vol+	 Return	 Back / Return
 TV CH-	 Shift + CH- /	 I<</Page-	 I<< / Preset-
 Tv Vol-	 Shift + Vol-	 >>I/Page+	 >>I / Preset+
 System	 Vol-	 <II/CH-	 CH- / Page-
 Tv Input	 Shift + AV / Input / RDS	 II>/CH+	 CH+ / Page+
 Power Tv	 Shift + Power	 <<	 << / Tune-
 Mute	 Mute / Dimmer	 >>	 >> / Tune+
 Up/FQ+	 Up	 Top Menu	 D.Menu / Top
 Left/ST-	 Left	 PGM	 TV/Radio /
 Enter	 OK	 Subtitle	 Subtitle / EQ
 Right/ST+	 Right	 RDM	 Shift + Display / Media
 Down/FQ-	 Down	 Audio	 Audio / Lang I/II
 Exit	 Exit / Cancel / Clear	 Disp	 Display / Media
 Menu	 Menu / Home	 Last Memory	 Shift + Back / Return
 Stop	 Stop / Hold	 Angle	 Info / Angle
 Play	 Play / Slow	 Repeat	 Shift + Green / APP / Repeat
 Pause	 Pause / Step / Freeze	 A-B	 Shift + YouTube / Repeat









































































Original	Substitut	Original	Substitut
 Source	 AV / Input / RDS	 0/10	 0
 Power	 Power	 C	 Fav / Marker / PC
 DVD	 Green / APP / Repeat	 Up / Pause	 Up
 TUN	 Red / Netflix / Search	 Left/ <<	 Left
 V1	 Blue / Prime Video / Random	 Enter/Play	 Play / Slow
 V2	 Shift + Blue / Prime	 Right/ >>	 >> / Tune+
 A1	 Yellow / YouTube / Repeat	 Down/Stop	 Stop / Hold
 A2	 Shift + Red / Netflix /	 Down/Stop	 Down
 1	 1	 Enter/Play	 OK
 2	 2	 Up / Pause	 Pause / Step / Freeze
 3	 3	 < /CH-/ <<<	 CH- / Page-
 4	 4	 >/CH+/ >>>	 CH+ / Page+
 5	 5	 Left/ <<	 << / Tune-
 6	 6	 Right/ >>	 Right
 7	 7	 1 V2	 Shift + 1
 8	 8	 2 V2	 Shift + 2
 9	 9	 3 V2	 Shift + 3





Original	Substitut	Original	Substitut
 Source	 AV / Input / RDS	 >10	 Guide / EPG / -/--
 Power	 Power	 0/10	 0
 DVD	 Green / APP / Repeat	 C	 Fav / Marker / PC
 TUN	 Red / Netflix / Search	 Up/Pause	 Up
 V1	 Blue / Prime Video / Random	 Left/ <<	 << / Tune-
 V2	 Shift + Blue / Prime	 Enter/Play	 OK
 A1	 Yellow / YouTube / Repeat	 Right/ >>	 >> / Tune+
 A2	 Shift + Red / Netflix /	 Down/Stop	 Stop / Hold
 1	 1	 Down/Stop	 Down
 2	 2	 Enter/Play	 Play / Slow
 3	 3	 Up/Pause	 Pause / Step / Freeze
 4	 4	 I<<	 I<< / Preset-
 5	 5	 >>I	 >>I / Preset+
 6	 6	 Left/ <<	 Left
 7	 7	 Right/ >>	 Right
 8	 8	 PGM/Top Menu	 TV/Radio /
 9	 9	 Subtitle/RDM	 Subtitle / EQ





Original	Substitut	Original	Substitut
Audio/Disp	Display / Media	Right/>> A2	Shift + >> /
Repeat	Shift + Green / APP /	Down/Stop A2	Shift + Down
1 A2	Shift + 1	Down/Stop A2	Shift + Stop /
2 A2	Shift + 2	Enter/Play A2	Shift + OK
3 A2	Shift + 3	Up/Pause A2	Shift + Up
4 A2	Shift + 4	I<< A2	Shift + I<< / Preset-
5 A2	Shift + 5	>>I A2	Shift + >>I / Preset+
6 A2	Shift + 6	Left/<< A2	Shift + Left
7 A2	Shift + 7	Right/>> A2	Shift + Right
8 A2	Shift + 8	PGM/Top Menu	Shift + TV/Radio / Program
9 A2	Shift + 9	RDM/Subtitle A2	Shift + Subtitle / EQ
>10 A2	Shift + Guide / EPG / -/-	Audio Disp A2	Shift + Display / Media
0/10 A2	Shift + 0	Repeat A2	Shift + Yellow / YouTube /
C A2	Shift + Fav / Marker / PC		
Up/Pause A2	Shift + Pause / Step /		
Left/<< A2	Shift + << /		
Enter/Play A2	Shift + Play /		

Slow

