Mandis shop

Yamaha V7769300

Original		Substitut	
STANDBY/ON	Standby		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Eject	SURROUND	Eject / Surround
TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
DISPLAY	Display	MEDIA DISPLAY	Display / Media
LEVEL +	Level +	CH+ PAGE	CH+ / Page+
LEVEL -	Level -	CH- PAGE	CH- / Page-
REP	Rep	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
INPUT	Input	RDS AV INPUT	AV / Input / RDS
	Stop	HOLD	Stop / Hold
	Play/Pause	SLOW	Play / Slow
>>/>>I		TUNE+	>> / Tune+
I<</<<		TUNE-	<< / Tune-

Original		Substitut	
PRESET	Preset Up	PRESET+	>>I / Preset+
PRESET	Preset Down	PRESET-	I<< / Preset-
TUNER ABCDE	ABCDE	SIZE ZOOM	Zoom / Size
PTY SEEK MODE	Mode PTY Seek	HOME MENU	Menu / Home
PTY SEEK START	Start PTY Seek	LIST SMART	Smart / List
FREQ/RDS	Freq/RDS	EQ SUBTITLE	Subtitle / EQ
BASS/TREBLE	Bass/Treble	TITLE SOUND	Sound / Title
B. BOOST	B. Boost	LANG I/II AUDIO	Audio / Lang I/II

https://mandis.ch/Yamaha/10523751-remote-substitution-for-Yamaha-CRX-TS10-RDS-V776930.htm