Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	<<</[≡o]	TUNE-	<< / Tune-
	>>/[≡?]	TUNE+	>> / Tune+
	I<<</[≡+]	PRESET-	I<< / Preset-
	>>I/[≡.]	PRESET+	>>I / Preset+
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	[≡i]	LIST SMART	Smart / List
TEXT	Text	GOTO TEXT	Text / Goto
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
FREEZE	Freeze	SHIFT + STEP-FREEZE	Shift + Pause / Step / Freeze

Original		Substitut	
INFO	Info	ANGLE INFO	Info / Angle
	[I]/Menu	HOME MENU	Menu / Home
	Up		Up
	Source	RDS AV INPUT	AV / Input / RDS
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL	Vol +	VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH	CH+	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
REC	REP/Rec	REC MODE	Rec / Rec Mode
CH	CH-	CH PAGE	CH- / Page-
1	1	TV 1	1

Original		Substitut		Original	Substitut
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
0	0	HDMI - SAT 0	0		
RECALL	Recall	RETURN BACK	Back / Return		

Original	Substitut	Original	Substitut
Power	Power	TXT/MIX	Text / Goto
Mute	Mute / Dimmer	Menu	Menu / Home
Play	Play / Slow	Up	Up
Pause	Pause / Step / Freeze	Info	Info / Angle
Stop	Stop / Hold	Left	Left
Rec	Rec / Rec Mode	Enter	OK
<<</Hold	<< / Tune-	Right	Right
>>/Index	>> / Tune+	Cancel	Exit / Cancel / Clear
I<<	I<< / Preset-	Down	Down
>>I	>>I / Preset+	Back	Back / Return
Nicam/A2	Audio / Lang I/II	Vol +	Vol +
Subtitle	Subtitle / EQ	List	Smart / List
Subpage	Eject / Surround	CH+	CH+ / Page+
Size	Zoom / Size	Vol -	Vol -
Sleep	Sleep / Timer	Mode	Display / Media
DTV/Radio	TV/Radio /	CH-	CH- / Page-
Reveal	D.Menu / Top Menu	1	1

Original	Substitut	Original	Substitut
2	DVD 2	FAV+	SHIFT + ▶ Shift + Right
3	CD - STB 3	-/--	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--
4	VIDEO 4		
5	TAPE 5		
6	TUNER 6		
7	AUX - HDD 7		
8	USB 8		
9	BLUETOOTH 9		
EPG	-/-- GUIDE EPG Guide / EPG / -/--		
0	HDMI - SAT 0		
FAV	PC FAV MARKER Fav / Marker / PC		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		
<<</ Hold	SHIFT + HOLD ■ Shift + Stop /		
FAV-	SHIFT + ◀ Shift + Left		

Original	Substitut	Original	Substitut
Power	Power	Up	Up
Mute	Mute / Dimmer	Info	Info / Angle
Play	Play / Slow	Left	Left
Pause	Pause / Step / Freeze	Ok	OK
Stop	Stop / Hold	Right	Right
Rec	Rec / Rec Mode	Exit	Exit / Cancel / Clear
<<</[Timer]	<< / Tune-	Down	Down
>>/[≡?]	>> / Tune+	Recall	Back / Return
I<<</[≡↕]	I<< / Preset-	Vol +	Vol +
>>I/[≡...]	>>I / Preset+	[≡i]	Smart / List
Audio	Audio / Lang I/II	Ch+	CH+ / Page+
Subtitle	Subtitle / EQ	Vol -	Vol -
I<<</[≡↕]	Zoom / Size	Ch-	CH- / Page-
<<</[Timer]	Sleep / Timer	1	1
Text	Text / Goto	2	2
Source/Av	AV / Input / RDS	3	3
[II]	Menu / Home	4	4

Original	Substitut	Original	Substitut
5	TAPE 5		
6	TUNER 6		
7	AUX - HDD 7		
8	USB 8		
9	BLUETOOTH 9		
Epg	-/-- GUIDE EPG	Guide / EPG / -/--	
0	HDMI - SAT 0		
Fav	PC FAV MARKER	Fav / Marker / PC	
Red	NETFLIX SEARCH	Red / Netflix / Search	
Green	APP REPEAT	Green / APP / Repeat	
Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat	
Blue	Prime Video RANDOM	Blue / Prime Video / Random	
Freeze	SHIFT + STEP - FREEZE	Shift + Pause / Step /	