Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	(O	LANG I/II AUDIO	Audio / Lang I/II
	[<>]	FORMAT PICTURE	Picture / Format
	Green/Timer	TIMER SLEEP	Sleep / Timer
	>I<	TOP MENU D.MENU	D.Menu / Top
	[1I2]	OPT-TOOLS SETUP	Setup / OPT /
	[≡]	GOTO TEXT	Text / Goto
	Source	RDS AV INPUT	AV / Input / RDS
	Menu	HOME MENU	Menu / Home
	Up		Up
	[i+]	ANGLE INFO	Info / Angle

Original		Substitut	
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Vol +	VOL +	Vol +
Active Control	[-O-]/Active Control	LIST SMART	Smart / List
P	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
P	P-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original	Substitut
9	9
Guide	Guide / EPG / -/--
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK

Original	Substitut
Right AMP	Shift + Right
Down AMP	Shift + Down
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0

Original	Substitut	Original	Substitut
P<P AMP	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		

Original	Substitut	Original	Substitut
Power	Power	P+	CH+ / Page+
Source	AV / Input / RDS	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
<<	<< / Tune-	1	1
Stop	Stop / Hold	2	2
Play	Play / Slow	3	3
Guide	Guide / EPG / -/--	4	4
[≡]	Text / Goto	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	[i+]	Info / Angle
>I<	D. Menu / Top	0	0
Menu	Menu / Home	P<P	Fav / Marker / PC
Vol +	Vol +	[1I2]	Setup / OPT /
Mute	Mute / Dimmer	[-O-]/Active Control	Smart / List

Original	Substitut	Original	Substitut
[<>]	FORMAT PICTURE Picture / Format		

Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	(O	LANG I/II AUDIO	Audio / Lang I/II
	[<>]	FORMAT PICTURE	Picture / Format
	Green/Timer	TIMER SLEEP	Sleep / Timer
	>I<	TOP MENU D.MENU	D.Menu / Top
	[1I2]	OPT-TOOLS SETUP	Setup / OPT /
	Source	RDS AV INPUT	AV / Input / RDS
	Menu	HOME MENU	Menu / Home
	Up		Up
	[i+]	ANGLE INFO	Info / Angle
	Left		Left

Original		Substitut	
	OK		OK
	Right		Right
	Down		Down
	Vol +	VOL	Vol +
	[-O-]/Active Control	LIST SMART	Smart / List
	P+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	P-	CH PAGE	CH- / Page-
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9

Original	Substitut
0	HDMI - SAT 0
P<P	PC FAV MARKER
Red	NETFLIX SEARCH
Green/Timer	APP REPEAT
Yellow/[ ]	YouTube REPEAT A-B
Blue/[...]	Prime Video RANDOM
Power VCR	SHIFT + Power
Play VCR	SHIFT + SLOW
Stop VCR	SHIFT + HOLD
Rec VCR	SHIFT + REC MODE
<< VCR	SHIFT + TUNE-
>> VCR	SHIFT + TUNE+
>I < VCR	SHIFT + TOP MENU D.MENU
Source VCR	SHIFT + RDS AV INPUT
Menu VCR	SHIFT + HOME MENU
Up VCR	SHIFT +
[i+] VCR	SHIFT + ANGLE INFO

Original	Substitut
Left VCR	SHIFT + Shift + Left
OK VCR	SHIFT + OK Shift + OK
Right VCR	SHIFT + Shift + Right
Down VCR	SHIFT + Shift + Down
P+ VCR	SHIFT + CH PAGE + Shift + CH+ /
P- VCR	SHIFT + CH PAGE − Shift + CH- /
1 VCR	SHIFT + TV 1 Shift + 1
2 VCR	SHIFT + DVD 2 Shift + 2
3 VCR	SHIFT + CD - STB 3 Shift + 3
4 VCR	SHIFT + VIDEO 4 Shift + 4
5 VCR	SHIFT + TAPE 5 Shift + 5
6 VCR	SHIFT + TUNER 6 Shift + 6
7 VCR	SHIFT + AUX - HDD 7 Shift + 7
8 VCR	SHIFT + USB 8 Shift + 8
9 VCR	SHIFT + BLUETOOTH 9 Shift + 9
0 VCR	SHIFT + HDMI - SAT 0 Shift + 0
P<P VCR	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC

Original	Substitut	Original	Substitut
Power	Power	2	2
>>	>> / Tune+	3	3
<<	<< / Tune-	4	4
Stop	Stop / Hold	5	5
Play	Play / Slow	6	6
Guide	Guide / EPG / -/--	7	7
Up	Up	8	8
Left	Left	9	9
Right	Right	[i+]	Info / Angle
Down	Down	0	0
>I<	D. Menu / Top	P<P	Fav / Marker / PC
Vol +	Vol +		
Mute	Mute / Dimmer		
P+	CH+ / Page+		
Vol -	Vol -		
P-	CH- / Page-		
1	1		