# Mandis shop

Sony RM-SRM1

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| SLEEP Sleep | TIMER SLEEP Sleep / Timer | CLEAR Clear | CLEAR EXIT CANCEL Exit / Cancel / Clear |
| SELECT Clock/Timer | SHIFT + TIMER SLEEP Shift + Sleep / Timer | PLAY MODE Play Mode | SLOW ▶ Play / Slow |
| SET Clock/Timer Set | PROGRAM TV/RADIO TV/Radio / | REPEAT Repeat | APP REPEAT Green / APP / Repeat |
| I/⏻ Power | ⏻ Power | ENTER Enter | OK OK |
| FUNCTION Function | TOP MENU D.MENU D.Menu / Top | ⏮ I<< | PRESET- ⏮ I<< / Preset- |
| TUNER MEMORY Tuner Memory | TUNER 6 6 | VOL + Vol + | + VOL Vol + |
| DISPLAY Display | MEDIA DISPLAY Display / Media | ⏭ >>I | PRESET+ ⏭ >>I / Preset+ |
| TAPE Tape | TAPE 5 5 | EQ- EQ- | SHIFT + VOL – Shift + Vol - |
| ◀▶ <> Tape | SHIFT + TAPE 5 Shift + 5 | EQ EQ | EQ SUBTITLE Subtitle / EQ |
| ■ Stop Tape | SHIFT + HOLD ■ Shift + Stop / | EQ+ EQ+ | SHIFT + + VOL Shift + Vol + |
| TUNER/BAND Tuner/Band | SHIFT + TUNER 6 Shift + 6 | VOL – Vol - | VOL – Vol - |
| TUNING – Tuner/Band | CH PAGE – CH- / Page- | ◀◀ << | TUNE- ◀◀ << / Tune- |
| TUNING + Tuner/Band | + CH PAGE CH+ / Page+ | ▶▶ >> | TUNE+ ▶▶ >> / Tune+ |
| CD CD | CD-STB 3 3 | | |
| ►II Play CD | SHIFT + SLOW ▶ Shift + Play / | | |
| ►II Pause CD | STEP-FREEZE II Pause / Step / Freeze | | |
| ■ Stop CD | HOLD ■ Stop / Hold | | |

https://mandis.tv/a/Sony/1395-231-comment-substituer-sony-rm-srm1-177511.htm