Original		Substitut	
TV I/⏻	Power Tv		Power
I<<		PRESET-	I<< / Preset-
←		SHIFT +	Shift + Left
→·		SHIFT +	Shift + Right
>>I		PRESET+	>>I / Preset+
<<		TUNE-	<< / Tune-
Play		SLOW	Play / Slow
>>		TUNE+	>> / Tune+
SYNC MENU	Sync Menu	TOP MENU D.MENU	D.Menu / Top
Pause		STEP-FREEZE	Pause / Step / Freeze
Stop		HOLD	Stop / Hold
THEATRE	Theatre	LIST SMART	Smart / List
SCENE	Scene	MEDIA DISPLAY	Display / Media
[+]		FORMAT PICTURE	Picture / Format
[...]		EQ SUBTITLE	Subtitle / EQ
DIGITAL	Digital	SIZE ZOOM	Zoom / Size
ANALOG	Analog	TIMER SLEEP	Sleep / Timer

Original		Substitut	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
AD	AD	LANG I/II AUDIO	Audio / Lang I/II
[i+]/[?]		ANGLE INFO	Info / Angle
Source		RDS AV INPUT	AV / Input / RDS
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
Up			Up
Left			Left
OK	OK	OK	OK
Right			Right
RETURN	Return/Back	RETURN BACK	Back / Return
Down			Down
OPTIONS	Options	OPT-TOOLS SETUP	Setup / OPT /
HOME	Home	HOME MENU	Menu / Home
Red		NETFLIX SEARCH	Red / Netflix / Search
Green		APP REPEAT	Green / APP / Repeat
Yellow		YouTube REPEAT A-B	Yellow / YouTube / Repeat
Blue		Prime Video RANDOM	Blue / Prime Video / Random

Original		Substitut	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
[≡] / Text		GOTO TEXT	Text / Goto
0	0	HDMI - SAT 0	0
♥/ FAV		PC FAV MARKER	Fav / Marker / PC
Mute		DIMMER MUTE	Mute / Dimmer
Vol +		+ VOL	Vol +
Prog+		+ CH PAGE	CH+ / Page+
Recall		SHIFT + RETURN BACK	Shift + Back / Return
Vol -		VOL −	Vol -

Original		Substitut	
Prog-		CH PAGE −	CH- / Page-
Rec		REC MODE	Rec / Rec Mode
Rec Pause		SHIFT + STEP - FREEZE	Shift + Pause / Step /
Rec Stop		SHIFT + HOLD	Shift + Stop /

Original	Substitut	Original	Substitut
Power	Power	1	1
I <<	I << / Preset-	2	2
>>I	>>I / Preset+	3	3
<<	<< / Tune-	4	4
Play	Play / Slow	5	5
>>	>> / Tune+	6	6
Pause	Pause / Step / Freeze	7	7
Stop	Stop / Hold	8	8
[...]	Subtitle / EQ	9	9
AD	Audio / Lang I/II	0	0
[i+]/[?]	Info / Angle	Prog+	CH+ / Page+
Up	Up	Recall	Shift + Back / Return
Left	Left	Prog-	CH- / Page-
OK	OK	Rec	Rec / Rec Mode
Right	Right	Top Menu	D. Menu / Top
Return/Back	Back / Return	Menu	Menu / Home
Down	Down		

Original		Substitut	
I/⏻	Power	⏻	Power
I<<	I<< / Preset-	PRESET- ⏮	I<< / Preset-
←	SHIFT + ◀	Shift + Left
→	SHIFT + ▶	Shift + Right
>>I	>>I / Preset+	PRESET+ ⏭	>>I / Preset+
<<	<< / Tune-	TUNE- ◀◀	<< / Tune-
Play	Play / Slow	SLOW ▶	Play / Slow
>>	>> / Tune+	TUNE+ ▶▶	>> / Tune+
Pause	Pause / Step / Freeze	STEP·FREEZE ⏸	Pause / Step / Freeze
Stop	Stop / Hold	HOLD ■	Stop / Hold
AD	AD	LANG I/II AUDIO	Audio / Lang I/II
[i+]	[i+]	ANGLE INFO	Info / Angle
Up	▲	▲	Up
Left	◀	◀	Left
OK	OK	OK	OK
Right	▶	▶	Right
Return/Back	RETURN	RETURN BACK	Back / Return

Original		Substitut	
▼	Down	▼	Down
OPTIONS	Options	OPT-TOOLS SETUP	Setup / OPT /
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
Red		NETFLIX SEARCH	Red / Netflix / Search
Green		APP REPEAT	Green / APP / Repeat
Yellow		YouTube REPEAT A-B	Yellow / YouTube / Repeat
Blue		Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD·STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX·HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
[≡]/Text		GOTO TEXT	Text / Goto

Original		Substitut	
	0		0
	Top Menu		D. Menu / Top
	Menu		Menu / Home

Original	Substitut

Original	Substitut	Original	Substitut
Power	Power	Right	Right
I <<	I << / Preset-	Return/Back	Back / Return
←	Shift + Left	Down	Down
· →	Shift + Right	Home	Shift + Menu /
>>I	>>I / Preset+	1	1
<<	<< / Tune-	2	2
Play	Play / Slow	3	3
>>	>> / Tune+	4	4
Pause	Pause / Step / Freeze	5	5
Stop	Stop / Hold	6	6
[. . .]	Subtitle / EQ	7	7
AD	Audio / Lang I/II	8	8
[i +] / [?]	Info / Angle	9	9
Source	AV / Input / RDS	[≡] / Text	Text / Goto
Up	Up	0	0
Left	Left	Mute	Mute / Dimmer
OK	OK	Vol +	Vol +

Original	Substitut	Original	Substitut
Recall	SHIFT + RETURN BACK Shift + Back / Return		
Vol -	VOL Vol -		
Top Menu	TOP MENU D.MENU D. Menu / Top		
Menu	HOME MENU Menu / Home		