Original		Substitut	
POWER	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CH LIST	CH List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
BACK RETURN	Return/Back	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS

Original		Substitut	
	Left		Left
OK	OK	OK	OK
	Right		Right
	Home	TOP MENU D.MENU	D. Menu / Top
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
+ VOL	Vol +	+ VOL	Vol +
INFO	Info	ANGLE INFO	Info / Angle
PR	PR+	+ CH PAGE	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
PR	PR-	CH PAGE −	CH- / Page-
REC	Rec	REC MODE	Rec / Rec Mode
NICAM/II	Nicam I/II	LANG I/II AUDIO	Audio / Lang I/II
TEXT	Text	GOTO TEXT	Text / Goto
SUB-PAGE AD	AD/Subpage	TITLE SOUND	Sound / Title

Original		Substitut		Original		Substitut	
SIZE FAV	FAV/Size	PC FAV MARKER	Fav / Marker / PC				
SIZE FAV	FAV/Size	SIZE ZOOM	Zoom / Size				
HOLD QUICK	Quick/Hold	MEDIA DISPLAY	Display / Media				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
INDEX ▶/II	Play	SLOW ▶	Play / Slow				
INDEX ▶/II	Pause/Index	STEP-FREEZE II	Pause / Step / Freeze				
REVEAL ◀◀	<<</Reveal	TUNE- ◀◀	<< / Tune-				
MIX ▶▶	>>/Mix	TUNE+ ▶▶	>> / Tune+				
CANCEL ■	Stop/Cancel	HOLD ■	Stop / Hold				