| Original | | Substitut | |
|---|---|---|---|
| POWER | Power | | Power |
| REPEAT | Repeat | APP / REPEAT | Green / APP / Repeat |
| A-B | A-B | YouTube / REPEAT A-B | Yellow / YouTube / Repeat |
| OPEN/CLOSE | Open / Close | SURROUND | Eject / Surround |
| N/P | N / P | TOP MENU / D.MENU | D. Menu / Top |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| SUBTITLE | Subtitle | EQ / SUBTITLE | Subtitle / EQ |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| ANGLE | Angle | ANGLE / INFO | Info / Angle |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| LANGUAGE | Language | LANG I/II / AUDIO | Audio / Lang I/II |

| Original | | Substitut | |
|---|---|---|---|
| 0 | 0 | HDMI-SAT 0 | 0 |
| 10+ | 10+ | -/-- / GUIDE EPG | Guide / EPG / -/-- |
| TIME | Time | TIMER / SLEEP | Sleep / Timer |
| SETUP | Setup | OPT-TOOLS / SETUP | Setup / OPT / |
| | Up | | Up |
| TITLE | Title | TITLE / SOUND | Sound / Title |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| PBC | PBC | FORMAT / PICTURE | Picture / Format |
| | Down | | Down |
| MENU | Menu | HOME / MENU | Menu / Home |
| VOL- | Vol - | VOL - | Vol - |
| ZOOM | Zoom | SIZE / ZOOM | Zoom / Size |
| VOL+ | Vol + | + VOL | Vol + |
| RETURN | Return | RETURN / BACK | Back / Return |
| L/R | L / R | GOTO / TEXT | Text / Goto |

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| STEP Step | SHIFT + STEP-FREEZE Shift + Pause / Step / | | |
| SLOW Slow | SHIFT + SLOW Shift + Play / | | |
| PROGRAM Program | PROGRAM TV/RADIO TV/Radio / | | |
| CLEAR Clear | CLEAR EXIT CANCEL Exit / Cancel / Clear | | |
| MUTE Mute | DIMMER MUTE Mute / Dimmer | | |
| DISPLAY Display | MEDIA DISPLAY Display / Media | | |
| PREV I<< | PRESET- I<< / Preset- | | |
| NEXT >>I | PRESET+ >>I / Preset+ | | |
| REV << | TUNE- << / Tune- | | |
| FWD >> | TUNE+ >> / Tune+ | | |
| V-MODE V-Mode | LIST SMART Smart / List | | |
| STOP Stop | HOLD Stop / Hold | | |
| PLAY/PAUSE Play / Pause | SLOW Play / Slow | | |
| PLAY/PAUSE Play / Pause | STEP-FREEZE Pause / Step / Freeze | | |
| | | | |
| | | | |
| | | | |