Original		Substitut	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
TV	TV	MEDIA DISPLAY	Display / Media
TV	TV	SHIFT + TV 1	Shift + 1
POP-UP-M DR+	DR+/ Pop-Up-M	LIST SMART	Smart / List
ZOOM	*/ Zoom	SIZE ZOOM	Zoom / Size
	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0

Original		Substitut	
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
PIP	PIP/[ ]	FORMAT PICTURE	Picture / Format
DISC-M TEXT	Text/Disc-M	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home
END BACK	Back/End	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
+V	Vol +	+ VOL	Vol +
	Up		Up
P+	P+	+ CH PAGE	CH+ / Page+
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
–V	Vol -	VOL –	Vol -
P–	P-	CH PAGE –	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Substitut		Original		Substitut	
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
MARKER	Blue/Marker	Prime Video RANDOM	Blue / Prime Video / Random				
MARKER	Blue/Marker	PC FAV MARKER	Fav / Marker / PC				
	<<	TUNE-	<< / Tune-				
	Play	SLOW	Play / Slow				
	>>	TUNE+	>> / Tune+				
	Rec	REC MODE	Rec / Rec Mode				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Stop	HOLD	Stop / Hold				

Original		Substitut	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
POP-UP-M DR+	DR+/ Pop-Up-M	LIST SMART	Smart / List
ZOOM	*/ Zoom	SIZE ZOOM	Zoom / Size
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
PIP	PIP/[ ]	FORMAT PICTURE	Picture / Format

Original		Substitut	
DISC-M TEXT	Text	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
END BACK	Back/ End	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
+V	Vol +	+ VOL	Vol +
	Up		Up
P+	P+	+ CH PAGE	CH+ / Page+
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
-V	Vol -	VOL –	Vol -
P-	P-	CH PAGE –	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MARKER	Blue/ Marker	Prime Video RANDOM	Blue / Prime Video / Random

Original	Substitut	Original	Substitut
Blue/Marker	Fav / Marker / PC		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original		Substitut	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
POP-UP-M DR+	DR+/ Pop-Up-M	LIST SMART	Smart / List
ZOOM	*/ Zoom	SIZE ZOOM	Zoom / Size
	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
HOME	Home	SHIFT + HOME MENU	Shift + Menu / Home

Original		Substitut	
PIP	PIP/[ ]	FORMAT PICTURE	Picture / Format
DISC-M TEXT	Text	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
END BACK	Back/ End	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
+V	Vol +	+ VOL	Vol +
	Up		Up
P+	P+	+ CH PAGE	CH+ / Page+
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
-V	Vol -	VOL –	Vol -
P-	P-	CH PAGE –	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original	Substitut	Original	Substitut
MARKER Blue/Marker	Prime Video RANDOM Blue / Prime Video / Random		
MARKER Blue/Marker	PC FAV MARKER Fav / Marker / PC		
<<	TUNE- << / Tune-		
Play	SLOW Play / Slow		
>>	TUNE+ >> / Tune+		
Rec	REC MODE Rec / Rec Mode		
Pause	STEP-FREEZE Pause / Step / Freeze		
Stop	HOLD Stop / Hold		

Original		Substitut	
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold

Original	Substitut