Original	Substitut	Original	Substitut
On/Standby	Power	Up	Up
Display	Display / Media	Left	Left
DVD / BD	Shift + 2	Enter	OK
VCR / DVR	Shift + 4	Right	Right
CBL/SAT	Shift + 0	Setup	Setup / OPT /
Game	Shift + 8	Down	Down
AUX	Shift + 7	Return	Back / Return
TUNER	Shift + 6	Home/Audio	Menu / Home
TV / CD	Shift + 1	Home/Audio	Audio / Lang I/II
TV / CD	Shift + 3	I <<	I << / Preset-
PORT	Shift + 5	>>I	>>I / Preset+
PC	Shift + Fav / Marker / PC	<<	<< / Tune-
Muting	Mute / Dimmer	Play	Play / Slow
CH/Disc/Album	CH+ / Page+	>>	>> / Tune+
Vol +	Vol +	Pause	Pause / Step / Freeze
CH/Disc/Album	CH- / Page-	Stop	Stop / Hold
Vol -	Vol -	Movie Tv	Red / Netflix / Search

Original		Substitut		Original		Substitut	
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat	CLR SLEEP 12	CLR/Sleep/12	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
THX PLAY MODE	THX	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD-STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX-HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
+10 D.TUN DIMMER	+10/--/---10/Dimmer/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--				
+10 D.TUN DIMMER	+10/--/---10/Dimmer/D.Tun	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer				
0 11	0/11	HDMI-SAT 0	0				
CLR SLEEP 12	CLR/Sleep/12	PC FAV MARKER	Fav / Marker / PC				
CLR SLEEP 12	CLR/Sleep/12	TIMER SLEEP	Sleep / Timer				

Original	Substitut	Original	Substitut
Power	Power	Left	Left
DVD/BD	Shift + 2	Enter	OK
VCR / DVR	Shift + 4	Right	Right
CBL/SAT	Shift + 0	Setup	Setup / OPT /
Game	Shift + 8	Down	Down
AUX	Shift + 7	Return	Back / Return
TUNER	Shift + 6	Audio	Audio / Lang I/II
TV / CD	Shift + 3	I <<	I << / Preset-
TV / CD	Shift + 1	>>I	>>I / Preset+
PORT	Shift + 5	<<	<< / Tune-
PC	Shift + Fav / Marker / PC	Play	Play / Slow
Muting Receiver	Mute / Dimmer	>>	>> / Tune+
Vol + Receiver	Vol +	Pause	Pause / Step / Freeze
Vol - Receiver	Vol -	Stop	Stop / Hold
Top Menu	D. Menu / Top	Search	Red / Netflix / Search
Up	Up	Repeat	Green / APP / Repeat
Menu	Menu / Home	Random	Blue / Prime Video / Random

Original		Substitut		Original	Substitut
THX PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
--/--10 +10 D.TUN DIMMER	+10/ - - / - - 10/ D. Tu Dimmer	-/-- GUIDE EPG	Guide / EPG / - / - -		
11 0	0/ 11	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		
12 CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
12 CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Original		Substitut	
ON/STANDBY	Power		Power
BD/DVD	DVD / BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + USB 8	Shift + 8
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV/CD	SHIFT + CD - STB 3	Shift + 3
TV/CD	TV/CD	SHIFT + TV 1	Shift + 1
PORT	PORT	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
MUTING	Muting Receiver	DIMMER MUTE	Mute / Dimmer
CH DISC	CH/Disc+	CH PAGE +	CH+ / Page+
VOL	Vol + Receiver	VOL +	Vol +
ALBUM	CH/Disc-	CH PAGE -	CH- / Page-
VOL	Vol - Receiver	VOL -	Vol -
	Up		Up

Original		Substitut	
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO HOME	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random

Original		Substitut		Original	Substitut
THX PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
--/--10 +10 D.TUN DIMMER	+10/ - - / - - 10/ D. Tu Dimmer	-/-- GUIDE EPG	Guide / EPG / - / - -		
11 0	0/ 11	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
12 CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
12 CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		

Original	Substitut	Original	Substitut
Power Receiver	Power	Play	Play / Slow
Muting Receiver	Mute / Dimmer	>>	>> / Tune+
CH	CH+ / Page+	Pause	Pause / Step / Freeze
Vol +	Vol +	Stop	Stop / Hold
CH Disc/Album	CH- / Page-	Movie TV	Red / Netflix / Search
Vol -	Vol -	Music	Green / APP / Repeat
Up	Up	Game	Yellow / YouTube / Repeat
Left	Left	Stereo	Blue / Prime Video / Random
Enter	OK	1	1
Right	Right	2	2
Setup	Setup / OPT /	3	3
Down	Down	4	4
Return	Back / Return	5	5
Audio	Audio / Lang I/II	6	6
I <<	I << / Preset-	7	7
>>I	>>I / Preset+	8	8
<<	<< / Tune-	9	9

Original		Substitut		Original	Substitut
+10/- -/- -10/D. Tu Dimmer		Guide / EPG / -/- -			
+10/- -/- -10/D. Tu Dimmer		Shift + Mute / Dimmer			
0/11		0			
CLR/Sleep/12		Fav / Marker / PC			
CLR/Sleep/12		Exit / Cancel / Clear			
CLR/Sleep/12		Sleep / Timer			