Original		Substitut	
POWER	Power		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
FUNCTION	Function	TIMER AV	AV
SUBTITLE	Subtitle	AD SUBT	Subt
HOME	Home	HOME SMART	Smart
SLEEP	Sleep	PROG SLEEP	Sleep
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
INFO/MENU	Info Menu	DISPLAY INFO	Info
INFO/MENU	Info Menu	TOP MENU MENU	Menu
ENTER	Enter	OK	Ok
	Up		Up
	Preset+	CH +	Ch +
	Down		Down
	Preset-	CH -	Ch -
	Right/Tuning+		Right
	Left/Tuning-		Left
BACK	Back	RETURN BACK	Back

Original		Substitut	
TITLE/POPUP	Title/PopUp	APP MEDIA	Media
PLAY	Play	PLAY MODE	Play
PAUSE/STEP	Pause/Step		Pause
STOP	Stop		Stop
SCAN	Scan >>		>>
SCA	<< Scan		<<
SKIP	Skip >>I		>>I
SKIP	I << Skip		I <<
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
OPTICAL/TV SOUND	Optical Tv Sound	SEARCH TV/R	TV/R
SPEAKER LEVEL	Speaker Level	SETTINGS OPT	Options
RDS R	Red/RDS	A	Red
PTY G	Green/PTY	B	Green
PTY SEARCH Y	Yellow/PTY Searc	C	Yellow

Original		Substitut	
MONO/STEREO B	Blue/ Mono/ Stereo	D	Blue
CLEAR	Clear	CLEAR EXIT	Exit
REPEAT	Repeat	REPEAT TEXT	Text
*	*	SHIFT + 3	Shift + 3
AUDIO	Audio	SHIFT + SOUND DUAL	Shift + Dual
*	*	SHIFT + 6	Shift + 6
*	*	SHIFT + 9	Shift + 9
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Substitut	
	Tv Power	SHIFT +	Shift + Power
AV/INPUT	AV Input Tv	SHIFT + TIMER AV	Shift + AV
PR/CH	CH+ Tv	SHIFT + CH +	Shift + Ch +
PR/CH	CH- Tv	SHIFT + CH -	Shift + Ch -
VOL +	Vol + Tv	SHIFT +	Shift + Up
VOL -	Vol - Tv	SHIFT +	Shift + Down
MUTE	Mute Tv	SHIFT + MUTE	Shift + Mute