Original		Substitut	
I/⏻	Power		Power
THEATRE SYNC	Power Theatre	SHIFT +	Shift + Power
MENU	Menu	TOP MENU MENU	Menu
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return	RETURN BACK	Back
MUTING	Muting	MUTE	Mute
VOLUME +	Volume+	+ VOL	Vol +
–	Volume-	VOL –	Vol -
	Up		Up
ENTER	Enter	OK	Ok
	Down		Down
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
TUNING – SLOW	<<| ◁ / Tuning- Slow		<<

Original		Substitut	
TUNING + SLOW	I >/ >>/ Tuning+		>>
PRESET –	I <<| Preset-		I <<
PRESET +	>>I / Preset+		>>I
DISPLAY	[*] Display	DISPLAY INFO	Info
STEP REPLAY	← / Replay/ ◁ I Step	CH –	Ch -
STEP ADVANCE	Step I I >/ Advance/ · →	+ CH	Ch +
CLEAR	Clear	CLEAR EXIT	Exit
DISC SKIP	Disc Skip	FAV PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Substitut		Original	Substitut
0	0	0	0		
ANGLE	Angle	A	Red		
SUBTITLE D.TUNING	Subtitle/D.Tunin	AD SUBT	Subt		
AUDIO	Audio	SOUND DUAL	Dual		
DYNAMIC BASS	Dynamic Bass	D	Blue		
MOVIE/ MUSIC	Movie/Music	C	Yellow		
SOUND FIELD	Sound Field	B	Green		
PROGRESSIVE	Progressive	SETTINGS OPT	Options		
FUNCTION	Function	SEARCH TV/R	TV/R		
DISPLAY	Display	SHIFT +	DISPLAY INFO Shift + Info		
AMP MENU	AMP Menu	APP MEDIA	Media		
SLEEP	Sleep	PROG SLEEP	Sleep		
PICTURE NAVI	Picture Navi	-/-- GUIDE	Guide		

Original		Substitut	
TV I/⏻	Power	⏻	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/-- CLEAR	- / - -	-/-- GUIDE	Gui de
TV VOL +	TV Vol +	+ VOL	Vol +
–	TV Vol -	VOL –	Vol -
TV CH +	TV CH+	+ CH	Ch +
–	TV CH-	CH –	Ch -
TV/VIDEO	Tv/ Vi deo	SEARCH TV/R	TV/ R

Original	Substitut