Mandis shop

RCT3004

Original		Substitut		Original		Substitut	
	Red/ Sound	TITLE SOUND	Sound / Title	4	4	VIDEO 4	4
	Red/ Sound	NETFLIX SEARCH	Red / Netflix / Search	5	5	TAPE 5	5
	Green/ Picture	FORMAT PICTURE	Picture / Format	6	6	TUNER 6	6
	Green/ Picture	APP REPEAT	Green / APP / Repeat	7	7	AUX - HDD 7	7
	Yellow/ P.	YouTube REPEAT A-B	Yellow / YouTube / Repeat	8	8	USB 8	8
	Blue/ VT	Prime Video RANDOM	Blue / Prime Video / Random	9	9	BLUETOOTH 9	9
INO	Ino	LIST SMART	Smart / List		Mute	DIMMER MUTE	Mute / Dimmer
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /	O/AV	0/ AV	HDMI - SAT 0	0
STOP	Zoom-/ Stop		Down	O/AV	0/ AV	RDS AV INPUT	AV / Input / RDS
FUNC.VI	Zoom+/ Func VI		Up		Power		Power
	-	VOL −	Vol -				
	+	+ VOL	Vol +				
	Prog. -	CH PAGE −	CH- / Page-				
	Prog. +	+ CH PAGE	CH+ / Page+				
a→z 1	1	TV 1	1				
z→a 2	2	DVD 2	2				
3	3	CD - STB 3	3				

https://mandis.tv/catalogo/1647-808-mandis-shop-substituci-per-Tosh-RCT3004.html