Mandis shop

Samsung AH59-00004B

Original	Substitut	Original	Substitut
Power	Power	Vol +	Vol +
Timer On/Off	Sleep / Timer	Vol -	Vol -
Mute	Mute / Dimmer	Up/CD >>I	Up
Sound Mode	Sound / Title	Down/CDI <<	Down
Disc Skip	Picture / Format	Tuning Mode	OK
Program/Set	Menu / Home		
Aux	AV / Input / RDS		
Deck 1/2	TV/Radio /		
CD/Repeat	3		
Mono/St	Fav / Marker / PC		
Tuner/Band	6		
<< Tape	<< / Tune-		
>> Tape	>> / Tune+		
Stop Tape	+ Shift + Stop /		
<> Tape	5		
Stop CD	Stop / Hold		
Play/Pause CD	Play / Slow		

https://mandis.ca/ca/Samsung/10492-396-comment-de-substituer-per-Samsung-AH59-00004B.htm