Original	Substitut
Power	Power
Power USB/Audio	Smart / List
Open/Close	Eject / Surround
Power CD/FM	Shift + Power
CD/FM	3
Dock	Green / APP / Repeat
USB/Audio In	8
Preset/Album Up USB/Audio In	CH+ / Page+
Preset/Album	Up
Preset/Album Up CD/FM	Shift + Up
Preset/Album Down USB/Audio	CH- / Page-
Preset/Album	Down
Preset/Album Down CD/FM	Shift + Down
I<< USB/Audio In	Shift + I<< / Preset-
I<<	I<< / Preset-
I<< CD/FM	Left
>>I USB/Audio In	Shift + >>I / Preset+

Original	Substitut
>>I	>>I / Preset+
>>I CD/FM	Right
OK USB/Audio	5
OK	OK
OK CD/FM	Shift + OK
Play USB/Audio In	Shift + Play /
Play/Pause CD/FM	Pause / Step / Freeze
Play/Pause	Play / Slow
Vol+	Vol+
Vol-	Vol-
Menu USB/Audio	Shift + Display / Media
Stop USB/Audio In	>> / Tune+
Stop CD/FM	Shift + Stop /
Menu CD/FM	D.Menu / Top
Stop	Stop / Hold
Menu	Menu / Home
Display	Display / Media

Original		Substitut	
DISPLAY	Display CD/FM	FORMAT PICTURE	Picture / Format
DISPLAY	Display USB/Audio In	ANGLE INFO	Info / Angle
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SHUFFLE REPEAT	Repeat Shuffle CD/FM	RDS AV INPUT	AV / Input / RDS
SHUFFLE REPEAT	Repeat/Shuffle	TUNE-	<< / Tune-
SHUFFLE REPEAT	Repeat/Shuffle USB/Audio In	RETURN BACK	Back / Return
PROG	Prog CD/FM	OPT-TOOLS SETUP	Setup / OPT /
PROG	Prog	GOTO TEXT	Text / Goto
PROG	Prog USB/Audio In	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SOUND	Sound	TITLE SOUND	Sound / Title
CLOCK	Clock	Prime Video RANDOM	Blue / Prime Video / Random
TIMER SLEEP	Sleep/Timer	TIMER SLEEP	Sleep / Timer

Original	Substitut