Original		Substitut	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
CH SET	CH Set	LIST SMART	Smart / List
PAGE >	Page >	+ CH PAGE	CH+ / Page+
< PAGE	< Page	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH	Up/CH+		Up
CH	Down/CH-		Down
VOL ▶	Right		Right
◀ VOL	Left		Left
OK	OK	OK	OK
VOL ▶	Vol +	+ VOL	Vol +
◀ VOL	Vol -	VOL −	Vol -

Original		Substitut	
LAST	Red/Last	NETFLIX SEARCH	Red / Netflix / Search
TTX	Green/TTX	APP REPEAT	Green / APP / Repeat
PIP	Yellow/PIP	YouTube REPEAT A-B	Yellow / YouTube / Repeat
ZOOM	Blue/Zoom	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
BACK	Back	RETURN BACK	Back / Return
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
INFO	Info	ANGLE INFO	Info / Angle

Original		Substitut	Original	Substitut
SIG	SIG	MEDIA DISPLAY Display / Media		
FAV	FAV	PC FAV MARKER Fav / Marker / PC		
SAT	SAT	SHIFT + HDMI - SAT 0 Shift + 0		