Original		Substitut	
	[+]	SIZE ZOOM	Zoom / Size
POWER	Power		Power
	Source/[?]	RDS AV INPUT	AV / Input / RDS
	>>	TUNE+	>> / Tune+
	Red/Rec	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	<<	TUNE-	<< / Tune-
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Stop	HOLD	Stop / Hold
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Play	SLOW	Play / Slow
	Radio	PROGRAM TV/RADIO	TV/Radio /
	[≡]	GOTO TEXT	Text / Goto
	[ ]	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Down		Down

Original		Substitut	
	Left		Left
	Right		Right
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
	P+	CH PAGE +	CH+ / Page+
	P-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Substitut		Original		Substitut	
	[i+]	ANGLE INFO	Info / Angle				
	I-II	LANG I/II AUDIO	Audio / Lang I/II				
	[1I2]	EQ SUBTITLE	Subtitle / EQ				
	[:≡]	-/-- GUIDE EPG	Guide / EPG / -/--				
	[<>]	FORMAT PICTURE	Picture / Format				
	P<P	PC FAV MARKER	Fav / Marker / PC				
	♪/Smart	LIST SMART	Smart / List				
	[ ]/Smart	MEDIA DISPLAY	Display / Media				

Original	Substitut
Power SAT	SHIFT + Power (Shift + Power)
Power	Power
Source/[?]	RDS AV INPUT (AV / Input / RDS)
Source SAT	SHIFT + RDS AV INPUT (Shift + AV / Input / RDS)
>>	TUNE+ >> / Tune+
Red SAT	NETFLIX SEARCH (Red / Netflix / Search)
<<	TUNE- << / Tune-
Green SAT	APP REPEAT (Green / APP / Repeat)
Yellow SAT	YouTube REPEAT A-B (Yellow / YouTube / Repeat)
Stop	HOLD Stop / Hold
Play	SLOW Play / Slow
Blue SAT	Prime Video RANDOM (Blue / Prime Video / Random)
Radio	PROGRAM TV/RADIO (TV/Radio /
[≡]	GOTO TEXT (Text / Goto)
Up	Up
Up SAT	SHIFT + Up (Shift + Up)
Down	Down

Original	Substitut
Down SAT	SHIFT + Down (Shift + Down)
Left SAT	SHIFT + Left (Shift + Left)
Left	Left
Right SAT	SHIFT + Right (Shift + Right)
Right	Right
OK SAT	SHIFT + OK (Shift + OK)
OK	OK
[ ] SAT	SHIFT + RETURN BACK (Shift + Back / Return)
[ ]	RETURN BACK (Back / Return)
Menu SAT	TOP MENU D.MENU (D.Menu / Top)
Menu	HOME MENU (Menu / Home)
Vol +	VOL + (Vol +)
Vol -	VOL - (Vol -)
Mute	DIMMER MUTE (Mute / Dimmer)
P+ SAT	SHIFT + CH PAGE + (Shift + CH+ / Page-)
P+	CH PAGE + (CH+ / Page+)
P- SAT	SHIFT + CH PAGE - (Shift + CH- / Page-)

Original	Substitut
P-	CH- / Page-
1 SAT	Shift + 1
1	1
2 SAT	Shift + 2
2	2
3 SAT	Shift + 3
3	3
4 SAT	Shift + 4
4	4
5 SAT	Shift + 5
5	5
6 SAT	Shift + 6
6	6
7 SAT	Shift + 7
7	7
8 SAT	Shift + 8
8	8

Original	Substitut
9 SAT	Shift + 9
9	9
0 SAT	Shift + 0
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II
[<>]	Picture / Format
P<P	Fav / Marker / PC

Original	Substitut	Original	Substitut
Power	Power	2	2
>>	>> / Tune+	3	3
<<	<< / Tune-	4	4
Stop	Stop / Hold	5	5
Play	Play / Slow	6	6
Radio	TV/ Radio /	7	7
[ ]	Back / Return	8	8
Up	Up	9	9
Down	Down	0	0
Left	Left	[i+]	Info / Angle
Right	Right	I - II	Audio / Lang I/II
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute / Dimmer		
P+	CH+ / Page+		
P-	CH- / Page-		
1	1		

Original	Substitut	Original	Substitut
Power AMP	SHIFT + Power: Shift + Power	MENU: Menu	HOME MENU: Menu / Home
Power	Power	MENU: Menu AMP	TOP MENU D.MENU: D. Menu / Top
Source/[?]	RDS AV INPUT: AV / Input / RDS	Up AMP	SHIFT + ▲: Shift + Up
>>	TUNE+ ▶▶: >> / Tune+	Up	▲: Up
>> AMP	PRESET+ ▶▶I: >>I / Preset+	Down	▼: Down
Red	NETFLIX SEARCH: Red / Netflix / Search	Down AMP	SHIFT + ▼: Shift + Down
Rec	REC MODE ●: Rec / Rec Mode	Left	◀: Left
<< AMP	PRESET- I◀◀: I<< / Preset-	Left AMP	SHIFT + ◀: Shift + Left
Green	APP REPEAT: Green / APP / Repeat	Right	▶: Right
<<	TUNE- ◀◀: << / Tune-	Right AMP	SHIFT + ▶: Shift + Right
Yellow	YouTube REPEAT A-B: Yellow / YouTube / Repeat	OK	OK: OK
Stop	HOLD ■: Stop / Hold	OK AMP	SHIFT + OK: Shift + OK
Blue	Prime Video RANDOM: Blue / Prime Video / Random	Vol + AMP	SHIFT + LIST SMART: Shift + Smart / List
Play	SLOW ▶: Play / Slow	Vol +	+ VOL: Vol +
Radio AMP	PROGRAM TV/RADIO: TV/Radio /	Vol -	VOL −: Vol -
[≡] AMP	GOTO TEXT: Text / Goto	Mute AMP	SHIFT + DIMMER MUTE: Shift + Mute / Dimmer
[ ]	RETURN BACK: Back / Return	Mute	DIMMER MUTE: Mute / Dimmer

Original	Substitut
P+	CH+ / Page+
P+ AMP	Shift + CH+ /
P- AMP	Shift + CH- /
P-	CH- / Page-
1 AMP	Shift + 1
1	1
2 AMP	Shift + 2
2	2
3 AMP	Shift + 3
3	3
4 AMP	Shift + 4
4	4
5 AMP	Shift + 5
5	5
6 AMP	Shift + 6
6	6
7 AMP	Shift + 7

Original	Substitut
7	7
8 AMP	Shift + 8
8	8
9 AMP	Shift + 9
9	9
0 AMP	Shift + 0
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II
[1I2] AMP	Subtitle / EQ
[+]	Zoom / Size
[<>]	Picture / Format
P<P	Fav / Marker / PC
♪/Smart	Smart / List
[ ]/Smart	Display / Media