Mandis shop

RM-V730U

Original		Substitut	
T ZOOM	Zoom T	CH PAGE +	CH+ / Page+
START/STOP	Star/Stop		Power
ZOOM W	Zoom W	CH PAGE −	CH- / Page-
SNAPSHOT	Snapshot	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
−	-	VOL −	Vol -
^	Up	▲	Up
+	+	+ VOL	Vol +
<<	<<	TUNE- ◀◀	<< / Tune-
<	Left	◀	Left
SET	SET	OPT-TOOLS SETUP	Setup / OPT /
SET	Play	SLOW ▶	Play / Slow
SET	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
>	Right	▶	Right
>>	>>	TUNE+ ▶▶	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
v	Down	▼	Down

Original		Substitut	
⏭	>>I	PRESET+ ⏭	>>I / Preset+
PLAYLIST	Playlist	MEDIA DISPLAY	Display / Media
DATE	Date	TIMER SLEEP	Sleep / Timer
INDEX	Index	LIST SMART	Smart / List

https://mandis.at/c/JVC-RM-V730U-ersatzfernbedienung-ersatzteile-JVC-RM-V730U