Original	Substitut	Original	Substitut
Standby/On	Power	Left	Left
Power CD/SACD Player	Smart / List	Enter	OK
Play CD/SACD	Play / Slow	Right	Right
Pause CD/SACD Player	Pause / Step / Freeze	Setup	Setup / OPT /
I<< CD/SACD	I<< / Preset-	Down	Down
Stop CD/SACD	Stop / Hold	Return	Back / Return
>>I CD/SACD	>>I / Preset+	Volume+	Vol +
Power Network Audio Player	Shift + Smart / List	Mute	Mute / Dimmer
Play Network Audio Player	Shift + Play /	Volume-	Vol -
Pause Network Audio Player	Shift + Pause / Step /	Phono	1
Source Network Audio Player	AV / Input / RDS	CD/SACD	2
I<< Network Audio Player	Shift + I<< / Preset-	Line 1	3
Stop Network Audio Player	Shift + Stop /	Line 2	4
>>I Network Audio Player	Shift + >>I / Preset+	Line 3	5
Top Menu	D.Menu / Top	Line 4	6
Now Playing	Info / Angle	Coaxial	7
Up	Up	Optical	8

Original	Substitut	Original	Substitut
DIRECT Direct	GUIDE EPG Guide / EPG / -/--		
LOUDNESS Loudness	HDMI - SAT 0 0		