Original	Substitut	Original	Substitut
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 TUNER 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 TUNER 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 TUNER 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR 1	SHIFT + VIDEO 4 Shift + 4	4 TUNER 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 TUNER 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 TUNER 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- TUNER >=10	-/-- GUIDE EPG Guide / EPG / -/--
SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original	Substitut	Original	Substitut
TUNER 7	7		
TUNER 8	8		
TUNER 9	9		
TUNER 0	0		
TAPE <<	<< / Tune-		
TAPE >>	>> / Tune+		
TAPE Deck 1/2	OK		
TAPE Rev. Play	Left		
TAPE Pause	Pause / Step / Freeze		
TAPE Stop	Stop / Hold		
TAPE Play	Play / Slow		
TAPE Play	Right		
Muting	Mute / Dimmer		
Volume-	Vol -		
Volume+	Vol +		

Original	Substitut	Original	Substitut
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 CD 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 CD 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 CD 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR1	SHIFT + VIDEO 4 Shift + 4	4 CD 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 CD 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 CD 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- CD >=10	-/-- GUIDE EPG Guide / EPG / -/--
SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original		Substitut		Original	Substitut
7	CD 7	AUX - HDD 7	7		
8	CD 8	USB 8	8		
9	CD 9	BLUETOOTH 9	9		
0	CD 0	HDMI - SAT 0	0		
|<<	CD |<<	PRESET- |<<	|<< / Preset-		
>>|	CD >>|	PRESET+ >>|	>>| / Preset+		
<<	CD <<	TUNE- <<	<< / Tune-		
>>	CD >>	TUNE+ >>	>> / Tune+		
II	CD Pause	STEP - FREEZE II	Pause / Step / Freeze		
■	CD Stop	HOLD ■	Stop / Hold		
▶	CD Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
– VOLU	Volume-	VOL –	Vol -		
LUME +	Volume+	+ VOL	Vol +		

Original	Substitut	Original	Substitut
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 VDP 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 VDP 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 VDP 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR1	SHIFT + VIDEO 4 Shift + 4	4 VDP 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 VDP 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 VDP 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- VDP >=10	-/-- GUIDE EPG Guide / EPG / -/--
SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original		Substitut		Original	Substitut
7	VDP 7	AUX - HDD 7	7		
8	VDP 8	USB 8	8		
9	VDP 9	BLUETOOTH 9	9		
0	VDP 0	HDMI - SAT 0	0		
⏮	VDP I <<	PRESET- ⏮	I << / Preset-		
⏭	VDP >>I	PRESET+ ⏭	>>I / Preset+		
◀◀	VDP <<	TUNE- ◀◀	<< / Tune-		
▶▶	VDP >>	TUNE+ ▶▶	>> / Tune+		
⏸	VDP Pause	STEP - FREEZE ⏸	Pause / Step / Freeze		
■	VDP Stop	HOLD ■	Stop / Hold		
▶	VDP Play	SLOW ▶	Play / Slow		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLUME –	Volume-	VOL –	Vol -		
VOLUME +	Volume+	+ VOL	Vol +		

Original	Substitut	Original	Substitut
RECEIVER Power Receiver	Power	3 STEREO 3 Stereo	LANG I/II AUDIO Audio / Lang I/II
AUDIO Power Audio	NETFLIX SEARCH Red / Netflix / Search	TEST Test	GOTO TEXT Text / Goto
TV Power TV	Prime Video RANDOM Blue / Prime Video / Random	CH SELECT CH Select	OPT-TOOLS SETUP Setup / OPT /
VCR Power VCR	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	HELP Help	ANGLE INFO Info / Angle
VDP Power VDP	YouTube REPEAT A-B Yellow / YouTube / Repeat	DISC Disc	LIST SMART Smart / List
CD Power CD	APP REPEAT Green / APP / Repeat	DISC ENTER Disc Enter	MEDIA DISPLAY Display / Media
TAPE Power TAPE	SHIFT + APP REPEAT Shift + Green / APP /	TV/AV TV / AV	RDS AV INPUT AV / Input / RDS
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	1 VCR 1 1	TV 1 1
CD CD	SHIFT + CD-STB 3 Shift + 3	2 VCR 1 2	DVD 2 2
TAPE TAPE	SHIFT + TAPE 5 Shift + 5	3 VCR 1 3	CD-STB 3 3
TV TV	SHIFT + TV 1 Shift + 1	DIRECT TUNING Direct Tuning	HOME MENU Menu / Home
VDP/ VDP 6CH VDP / VDP 6CH	SHIFT + DVD 2 Shift + 2	TV VOL+ TV Vol +	SHIFT + + VOL Shift + Vol +
VCR 1 VCR1	SHIFT + VIDEO 4 Shift + 4	4 VCR 1 4	VIDEO 4 4
VCR 2 VCR 2	SHIFT + AUX-HDD 7 Shift + 7	5 VCR 1 5	TAPE 5 5
CH LEVEL − CH Level -	CH PAGE − CH- / Page-	6 VCR 1 6	TUNER 6 6
CH LEVEL + CH Level +	+ CH PAGE CH+ / Page+	≥10/-/-- VCR 1 >=10	-/-- GUIDE EPG Guide / EPG / -/--
SURROUND Surround	SURROUND Eject / Surround	TV VOL− TV Vol -	SHIFT + VOL − Shift + Vol -

Original	Substitut	Original	Substitut
VCR 1 7	7		
VCR 1 8	8		
VCR 1 9	9		
VCR 1 0	0		
VCR 1 <<	<< / Tune-		
VCR 1 >>	>> / Tune+		
VCR 1 Pause	Pause / Step / Freeze		
VCR 1 Stop	Stop / Hold		
VCR 1 Play	Play / Slow		
Muting	Mute / Dimmer		
Volume-	Vol -		
Volume+	Vol +		