Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
ADVANCE	Advance	EQ SUBTITLE	Subtitle / EQ
OPEN•CLOSE	Open/Close	SURROUND	Eject / Surround
AGAIN	Again	FORMAT PICTURE	Picture / Format
ZOOM LIST	Zoom	SIZE ZOOM	Zoom / Size
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
LIVE	Live	OPT-TOOLS SETUP	Setup / OPT /
TEXT	Text	GOTO TEXT	Text / Goto
AV	AV	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home

Original		Substitut	
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
BACK	Back	RETURN BACK	Back / Return
	Vol +	VOL +	Vol +
TEXT	Violet	LIST SMART	Smart / List
PR	PR+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
PR	PR-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Substitut		Original	Substitut
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
OPEN•CLOSE	Red	NETFLIX SEARCH	Red / Netflix / Search		
ZOOM LIST	Green	APP REPEAT	Green / APP / Repeat		
INFO	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
GUIDE	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
ZOOM LIST	List	SHIFT +	LIST SMART	Shift + Smart / List	

Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
ADVANCE	Advance	EQ SUBTITLE	Subtitle / EQ
OPEN•CLOSE	Open/Close	SURROUND	Eject / Surround
AGAIN	Again	FORMAT PICTURE	Picture / Format
ZOOM LIST	Zoom	SIZE ZOOM	Zoom / Size
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
LIVE	Live	OPT-TOOLS SETUP	Setup / OPT /
TEXT	Text	GOTO TEXT	Text / Goto
AV	AV	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home

Original		Substitut	
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
BACK	Back	RETURN BACK	Back / Return
	Vol +	VOL +	Vol +
TEXT	Violet	LIST SMART	Smart / List
PR	PR+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
PR	PR-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Substitut		Original	Substitut
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
OPEN•CLOSE	Red	NETFLIX SEARCH	Red / Netflix / Search		
ZOOM LIST	Green	APP REPEAT	Green / APP / Repeat		
INFO	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
GUIDE	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
ZOOM LIST	List	SHIFT +	LIST SMART	Shift + Smart / List	

Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
ADVANCE	Advance	EQ SUBTITLE	Subtitle / EQ
OPEN•CLOSE	Open/Close	SURROUND	Eject / Surround
AGAIN	Again	FORMAT PICTURE	Picture / Format
ZOOM LIST	Zoom	SIZE ZOOM	Zoom / Size
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
LIVE	Live	OPT-TOOLS SETUP	Setup / OPT /
TEXT	Text	GOTO TEXT	Text / Goto
AV	AV	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home

Original		Substitut	
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
BACK	Back	RETURN BACK	Back / Return
	Vol +	VOL +	Vol +
TEXT	Violet	LIST SMART	Smart / List
PR	PR+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
PR	PR-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Substitut		Original	Substitut
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
OPEN•CLOSE	Red	NETFLIX SEARCH	Red / Netflix / Search		
ZOOM LIST	Green	APP REPEAT	Green / APP / Repeat		
INFO	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
GUIDE	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
ZOOM LIST	List	SHIFT +	LIST SMART	Shift + Smart / List	