Mandis shop

F. E. T. TP711

Original		Substitut	
1	1	1	1
2	2	2	2
3	3	3	3
Power	Power	Power	Power
4	4	4	4
5	5	5	5
6	6	6	6
Brightness+	Brightness+	>>I / Preset+	>>I / Preset+
7	7	7	7
8	8	8	8
9	9	9	9
Brightness-	Brightness-	I<< / Preset-	I<< / Preset-
PC/AUX	PC/AUX	AV / Input / RDS	AV / Input / RDS
0/AV	0/AV	0	0
TXT	TXT	Text / Goto	Text / Goto
Color+	Color+	>> / Tune+	>> / Tune+
P+	P+	CH+ / Page+	CH+ / Page+

Original		Substitut	
Up	Up	Up	Up
Color-	Color-	<< / Tune-	<< / Tune-
Left	Left	Left	Left
Vol -	Vol -	Vol -	Vol -
OK	OK	OK	OK
Right	Right	Right	Right
Vol +	Vol +	Vol +	Vol +
i	i	Info / Angle	Info / Angle
Down	Down	Down	Down
P-	P-	CH- / Page-	CH- / Page-
Mute	Mute	Mute / Dimmer	Mute / Dimmer

https://mandis.at/c/F.E.T./1696229-remote-substitution-F.E.T.-TP711.htm