Mandis shop

RM-SEP30

Original		Substitut	
I/⏻	Power	⏻	Power
VOLUME +	Volume+	VOL +	Vol +
MUSIC MENU	Music Menu	HOME MENU	Menu / Home
MEGA BASS	Mega Bass	TITLE SOUND	Sound / Title
–	Volume-	VOL –	Vol -
TAPE	Tape	TAPE 5	5
CD/ REMAIN	CD/Remain	CD-STB 3	3
TUNER/ BAND	Tuner/Band	TUNER 6	6
PRESET +	Preset +	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+
TUNING/ CLOCK/TIMER +	Tuning/Clock/Timer +	TUNE+ ▶▶	>> / Tune+
TUNER MEM/ ENTER/PGM	Tuner	OK	OK
PRESET –	Preset -	SHIFT + PRESET- ⏮	Shift + I<< / Preset-
TUNING/ CLOCK/TIMER –	Tuning/Clock/Timer -	TUNE- ◀◀	<< / Tune-
SHUFFLE	Shuffle	LIST SMART	Smart / List
►II	Play	SLOW ▶	Play / Slow
►II	Pause	STEP-FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold

Original		Substitut	
⏮	I<<</<<	PRESET- ⏮	I<< / Preset-
⏭	>>/>>I	PRESET+ ⏭	>>I / Preset+
CLOCK/TIMER/ SLEEP SET	Clock/Timer/Sleep Set	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	Timer On/Off	PC FAV MARKER	Fav / Marker / PC
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

https://mandis.at/c/Sony/1082-350-comfort-de-substitution-per-Sony-RM-SEP30-1768271.htm