Original	Substitut	Original	Substitut
On / Standby	Power	Volume+	Vol +
CBL/SAT	SHIFT + HDMI - SAT 0 Shift + 0	CH/Page-	CH- / Page-
DVD	SHIFT + DVD 2 Shift + 2	SLEEP	Sleep / Timer
TV Audio	LANG I/II AUDIO Audio / Lang I/II	MUTE	Mute / Dimmer
Blu-ray	SHIFT + TV 1 Shift + 1	Volume-	Vol -
AUX1	SHIFT + AUX - HDD 7 Shift + 7	INFO	Info / Angle
M-XP	PC FAV MARKER Fav / Marker / PC	Up	Up
Tuner	SHIFT + TUNER 6 Shift + 6	OPTION	SHIFT + OPT-TOOLS SETUP Shift + Setup / OPT / Tools
Game	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	OPTION	TOP MENU D.MENU D. Menu / Top
AUX2	SHIFT + VIDEO 4 Shift + 4	Left	Left
Phono	SHIFT + BLUETOOTH 9 Shift + 9	ENTER	OK
iPod/USB	SHIFT + USB 8 Shift + 8	Right	Right
Media Player	SHIFT + TAPE 5 Shift + 5	BACK	RETURN BACK Back / Return
CD	SHIFT + CD - STB 3 Shift + 3	Down	Down
Network	GUIDE EPG Guide / EPG / -/--	SETUP	OPT-TOOLS SETUP Setup / OPT /
Internet Radio	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	Pause	STEP - FREEZE Pause / Step / Freeze
CH/PAGE	CH PAGE CH+ / Page+	Stop	HOLD Stop / Hold

Original		Substitut	
	Play	SLOW	Play / Slow
TUNE	I<<Tune-	SHIFT + TUNE-	Shift + << /
TUNE	I<<Tune-	PRESET-	I<< / Preset-
TUNE +	Tune+/ >>I	SHIFT + TUNE+	Shift + >> /
TUNE +	Tune+/ >>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
1	Favorite Station	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
FAVORITE 2	Favorite Station	SHIFT + APP REPEAT	Shift + Green / APP /
STATION 3	Favorite Station	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
4	Favorite Station	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
MOVIE	Red/Movie	NETFLIX SEARCH	Red / Netflix / Search
MUSIC	Green/Music	APP REPEAT	Green / APP / Repeat
GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1	TV 1	1
SOUND 2	2	DVD 2	2

Original		Substitut	
MODE 3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original	Substitut	Original	Substitut
On / Standby	Power	Volume+	Vol +
CBL/SAT	SHIFT + HDMI - SAT 0 — Shift + 0	CH/Page-	CH- / Page-
DVD	SHIFT + DVD 2 — Shift + 2	SLEEP	Sleep / Timer
Tv Audio	LANG I/II AUDIO — Audio / Lang I/II	MUTE	Mute / Dimmer
Blu-ray	SHIFT + TV 1 — Shift + 1	Volume-	Vol -
AUX1	SHIFT + AUX - HDD 7 — Shift + 7	Up	Up
M-XP	PC FAV MARKER — Fav / Marker / PC	Left	Left
Tuner	SHIFT + TUNER 6 — Shift + 6	Right	Right
Game	SHIFT + PC FAV MARKER — Shift + Fav / Marker / PC	BACK	Back / Return
AUX2	SHIFT + VIDEO 4 — Shift + 4	Down	Down
PHONO	SHIFT + BLUETOOTH 9 — Shift + 9	Pause	Pause / Step / Freeze
iPod/USB	SHIFT + USB 8 — Shift + 8	Stop	Stop / Hold
MEDIA PLAYER	SHIFT + TAPE 5 — Shift + 5	Play	Play / Slow
CD	SHIFT + CD - STB 3 — Shift + 3	TUNE I<</ Tune-	SHIFT + TUNE- — Shift + << /
NETWORK	GUIDE EPG — Guide / EPG / -/--	TUNE I<</ Tune-	PRESET- — I<< / Preset-
INTERNET RADIO	SHIFT + GUIDE EPG — Shift + Guide / EPG / -/--	TUNE >>I / Tune+	SHIFT + TUNE+ — Shift + >> /
CH/PAGE	CH + PAGE — CH+ / Page+	TUNE >>I / Tune+	PRESET+ — >>I / Preset+

Original		Substitut		Original	Substitut
<<	<<	TUNE-	<< / Tune-		
>>	>>	TUNE+	>> / Tune+		
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search		
FAVORITE 2	Favorite Station	APP REPEAT	Green / APP / Repeat		
STATION 3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
SOUND 2	2	DVD 2	2		
MODE 3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
ENTER	Enter	OK	OK		

Original	Substitut	Original	Substitut
ON / Standby	Power	Volume+	Vol +
CBL/SAT	SHIFT + 0 (HDMI - SAT) Shift + 0	CH/Page-	CH- / Page-
DVD	SHIFT + 2 (DVD) Shift + 2	SLEEP	Sleep / Timer
Tv Audio	LANG I/II AUDIO Audio / Lang I/II	MUTE	Mute / Dimmer
Blu-ray	SHIFT + 1 (TV) Shift + 1	Volume-	Vol -
AUX1	SHIFT + 7 (AUX - HDD) Shift + 7	Up	Up
M-XP	PC FAV MARKER Fav / Marker / PC	Left	Left
Tuner	SHIFT + 6 (TUNER) Shift + 6	Right	Right
Game	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	BACK	RETURN BACK Back / Return
AUX2	SHIFT + 4 (VIDEO) Shift + 4	Down	Down
PHONO	SHIFT + 9 (BLUETOOTH) Shift + 9	Pause	STEP - FREEZE Pause / Step / Freeze
iPod/USB	SHIFT + 8 (USB) Shift + 8	Stop	HOLD Stop / Hold
MEDIA PLAYER	SHIFT + 5 (TAPE) Shift + 5	Play	SLOW Play / Slow
CD	SHIFT + 3 (CD - STB) Shift + 3	– TUNE I <<< / Tune-	SHIFT + TUNE- Shift + <<< /
NETWORK	-/-- GUIDE EPG Guide / EPG / -/--	– TUNE I <<< / Tune-	PRESET- I <<< / Preset-
INTERNET RADIO	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	NE + >>I / Tune+	SHIFT + TUNE+ Shift + >>> /
CH/PAGE	CH+ / Page+	NE + >>I / Tune+	PRESET+ >>I / Preset+

Original		Substitut		Original	Substitut
<<	<<	TUNE- <<	<< / Tune-		
>>	>>	TUNE+ >>	>> / Tune+		
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search		
FAVORITE 2	Favorite Station	APP REPEAT	Green / APP / Repeat		
STATION 3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
SOUND 2	2	DVD 2	2		
MODE 3	3	CD-STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX-HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI-SAT 0	0		
ENTER	Enter	OK	OK		