Original		Substitut	
EJECT	Eject	SURROUND	Eject / Surround
TV/MAGN	Tv/Magn	PROGRAM TV/RADIO	TV/Radio /
	Power		Power
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
EXECUTE	Execute	OK	OK
WIDE	Wide	SIZE ZOOM	Zoom / Size
	Left		Left
	Right		Right
SHOWVIEW	Showview	FORMAT PICTURE	Picture / Format
	Down		Down
ANNUL PROGRAM	Annul Program	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CHOIX SON	Choix Son	TITLE SOUND	Sound / Title
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
REMISE A ZERO	Remise a Zero	RETURN BACK	Back / Return

Original		Substitut	
COMPT/ DUREE REST	Compt/Duree	LIST SMART	Smart / List
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
IMAGE	< Wheel / <	SHIFT + PRESET-	Shift + I<< / Preset-
IMAGE	Wheel >/ Frame	SHIFT + PRESET+	Shift + >>I / Preset+
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DOUBL SON	Doubl. Son	LANG I/II AUDIO	Audio / Lang I/II
AFFICH	Affich	MEDIA DISPLAY	Display / Media
	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
ENVOI	Envoi	PC FAV MARKER	Fav / Marker / PC
CHOIX ENTREE	Choix Entree	RDS AV INPUT	AV / Input / RDS
RECHER	I<< Index Search	PRESET-	I<< / Preset-
INDEX	Index Search >>I	PRESET+	>>I / Preset+

Original		Substitut	
VOL	Vol +	VOL	Vol +
CHAINE	Prog+	CH PAGE	CH+ / Page+
ENR	ENR	REC MODE	Rec / Rec Mode
VITESSE BANDE	Vitesse Bande	OPT-TOOLS SETUP	Setup / OPT /
PROG RAPIDE	Prog Rapide	TIMER SLEEP	Sleep / Timer
	Vol -	VOL	Vol -
	Prog-	CH PAGE	CH- / Page-
RET	<< Search	TUNE-	<< / Tune-
	Search >>	TUNE+	>> / Tune+
	Relect	ANGLE INFO	Info / Angle
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
LECTURE	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold

Original	Substitut

Original	Substitut
TV/ VTR	TV/ Radi o /
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
Red	Red / Netflix / Search
Green	Green / APP / Repeat
7	7
8	8
9	9
Yel l ow	Yel l ow / YouTube / Repeat
Di spl ay	Di spl ay / Medi a
Bl ue	Bl ue / Pri me Vi deo / Random
- / - -	Gui de / EPG / - / - -

Original	Substitut
0	0
Vol +	Vol +
Pr og+	CH+ / Page+
[ ]	Smart / List
[≡]	Text / Goto
Vol -	Vol -
Pr og-	CH- / Page-