| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| PROGRAM | Program | PROGRAM TV/RADIO | TV/Radio / |
| OPEN/CLOSE | Open/Close | SURROUND | Eject / Surround |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| PLAY/PAUSE | Play | SLOW | Play / Slow |
| C | C | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| SKIP/F | I<< Skip/Frame | PRESET- | I<< / Preset- |

| Original | | Substitut | |
|---|---|---|---|
| SLOW/SE | << Slow/Search | TUNE- | << / Tune- |
| /SEARCH | Slow/Search >> | TUNE+ | >> / Tune+ |
| /FRAME | Skip/Frame >>I | PRESET+ | >>I / Preset+ |
| PLAY/PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |
| STOP | Stop | HOLD | Stop / Hold |
| TITLE | Title | TITLE SOUND | Sound / Title |
| MENU | Menu | HOME MENU | Menu / Home |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| SEARCH MODE | Search Mode | NETFLIX SEARCH | Red / Netflix / Search |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| SELECT | Select | OK | OK |
| RETURN | Return | RETURN BACK | Back / Return |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |

| Original | | Substitut | | Original | Substitut |
|---|---|---|---|---|---|
| | Audio | | Audio / Lang I/II | | |
| | Angle | | Info / Angle | | |
|  | Time | | Sleep / Timer | | |
| | Repeat | | Green / APP / Repeat | | |
|  | A→B | | Yellow / YouTube / Repeat | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |