Original		Substitut	
POWER	Power	POWER	Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Text / Play/Paus	SLOW	Play / Slow
	Text / Play/Paus	STEP-FREEZE	Pause / Step / Freeze
	Text / Play/Paus	GOTO TEXT	Text / Goto
STILL	Still / Stop	HOLD	Stop / Hold
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
	Aspect / Size	SIZE ZOOM	Zoom / Size
	Red / <<	TUNE-	<< / Tune-
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
	Green / >>	APP REPEAT	Green / APP / Repeat
	Green / >>	TUNE+	>> / Tune+
	Yellow / I<<	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Yellow / I<<	PRESET-	I<< / Preset-
	Blue / >>I	PRESET+	>>I / Preset+
	Blue / >>I	Prime Video RANDOM	Blue / Prime Video / Random
SOURCE	Source	RDS AV INPUT	AV / Input / RDS

Original		Substitut	
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
INFO	Info	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL	Vol +	VOL	Vol +
INDEX	Index	MEDIA DISPLAY	Display / Media
CH	CH +	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
LIST	List	LIST SMART	Smart / List
CH	CH -	CH PAGE	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Substitut		Original	Substitut
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
AUDIO	Audio / I/II	LANG I/II AUDIO	Audio / Lang I/II		
0	0	HDMI - SAT 0	0		
DVB	DVB	TOP MENU D.MENU	D. Menu / Top		
♥	FAV	PC FAV MARKER	Fav / Marker / PC		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
	Prev. CH.	RETURN BACK	Back / Return		
	Cancel	SHIFT +	CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
USB	USB	SHIFT +	USB 8 Shift + 8		
	Rec	REC MODE	Rec / Rec Mode		