Mandis shop

JVC RM-MH18G

Original		Substitut	
STAND BY	Standby	SHIFT +	Shift + Power
ON	On		Power
HDMI 1	HDMI 1	TV 1	1
HDMI 2	HDMI 2	DVD 2	2
COMP.	COMP	VIDEO 4	4
3D FORMAT	3D Format	FORMAT PICTURE	Picture / Format
3D SETTING	3D Setting	OPT-TOOLS SETUP	Setup / OPT /
PC	PC	PC FAV MARKER	Fav / Marker / PC
LENS CONTROL	Lens Control	-/-- GUIDE EPG	Guide / EPG / -/--
LENS MEMORY	Lens Memory	HDMI - SAT 0	0
C.M.D.	C.M.D.	TUNER 6	6
HIDE	Hide	BLUETOOTH 9	9
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down

Original		Substitut	
MENU	Menu	HOME MENU	Menu / Home
BACK	Back	RETURN BACK	Back / Return
FILM	Film	APP REPEAT	Green / APP / Repeat
CINEMA	Cinema	YouTube REPEAT A-B	Yellow / YouTube / Repeat
ANIME.	Anime.	NETFLIX SEARCH	Red / Netflix / Search
NATURAL	Natural	AUX - HDD 7	7
STAGE	Stage	USB 8	8
3D	3D	SIZE ZOOM	Zoom / Size
THX	THX	GOTO TEXT	Text / Goto
USER	User	ANGLE INFO	Info / Angle
MPC	MPC	TAPE 5	5
GAMMA	Gamma	Prime Video RANDOM	Blue / Prime Video / Random
COLOR TEMP	Color Temp	MEDIA DISPLAY	Display / Media
COLOR PFILE	Color P.File	LIST SMART	Smart / List
PIC. ADJ.	Pic. Adj.	TOP MENU D.MENU	D.Menu / Top

https://mandis.ch/ca/JVC-1683-663-comment-substituir-per-JVC-RM-MH18G-P023359.htm