Mandis shop

LG COV33552407

Original		Substitut	
	Power		Power
SLEEP	Sleep	SHIFT +	Shift + Power
VOL +	Vol +	V+	V+
VOL -	Vol -	V-	V-
	Mute		Mute
F	F	1 SETUP	1 / Setup
PRESET/FOLDER	Preset / Folder Up		+
PRESET/FOLDER	Preset / Folder		-
PROGRAM /MEMORY	Program /	2 MENU	2 / Menu
DIMMER	Dimmer	9 DISP	9 / Disp
DELETE	Delete	3 EXIT	3 / Exit
SOUND EFFECT	Sound Effect	5 AUDIO	5 / Audio
REPEAT	Repeat	7 REP	7 / Rep
INFO	Info	4 MODE	4 / Mode
TUNING -	I<< / Tuning -	EQ	I<
▶/II	Play	BAND	Play / Band
▶/II	Pause	IIANG	II Ang

Original		Substitut	
TUNING +	>>I / Tuning +	CLEAR	>I
■	Stop	RANDOM ■	Stop / Random
RDS	RDS	-- SEAR	-- / Sear
PTY	PTY	0 ZOOM	0 / Zoom

https://mandis.cl/catalogo/mando-a-distancia-sustituciones-LG-COV33552407.html