Mandis shop

REMCON314

Original		Substitut	
POWER	Power	POWER	Power
EJECT	Eject	SURROUND	Eject / Surround
▲	Up	▲	Up
▶	Right	▶	Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
◀	Left	◀	Left
▼	Down	▼	Down
OK CLK/CNT	OK / Clk/Cnt	OK	OK
i	i	ANGLE INFO	Info / Angle
PAUSE/STILL	Pause/Still	STEP-FREEZE ⏸	Pause / Step / Freeze
FF	FF	TUNE+ ▶▶	>> / Tune+
REW	REW	TUNE- ◀◀	<< / Tune-
PLAY	Play	SLOW ▶	Play / Slow
STOP	Stop	HOLD ■	Stop / Hold
REC/ITR	Rec ITR	REC MODE ●	Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2

Original		Substitut	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV/VCR	TV/VCR	LIST SMART	Smart / List
0	0	HDMI-SAT 0	0
CM SKIP	CM Skip	PC FAV MARKER	Fav / Marker / PC
SHOWVIEW VIDEO Plus+	ShowView / Video Plus+	MEDIA DISPLAY	Display / Media
LP	LP	HOME MENU	Menu / Home
AV	AV	RDS AV INPUT	AV / Input / RDS
C.LOCK	C. Lock	TOP MENU D.MENU	D. Menu / Top
ez POWER OFF	ez POWER OFF	NETFLIX SEARCH	Red / Netflix / Search
ez REPEAT	ez REPEAT	APP REPEAT	Green / APP / Repeat

https://mandis.tv/a/1667-850-remote-substitution-67TP019H