| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| | <<  / [ ≡o] | TUNE- | << / Tune- |
| | >>/ [ ≡?] | TUNE+ | >> / Tune+ |
| | I <</ [ ≡+] | PRESET- | I << / Preset- |
| | >>I / [ ≡ . ] | PRESET+ | >>I / Preset+ |
| | Play | SLOW | Play / Slow |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| | [ ≡i ] | LIST SMART | Smart / List |
| TEXT | Text | GOTO TEXT | Text / Goto |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| FREEZE | Freeze | SHIFT + STEP-FREEZE | Shift + Pause / Step / Freeze |

| Original | | Substitut | |
|---|---|---|---|
| INFO | Info | ANGLE INFO | Info / Angle |
| | [ I ]/Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| | Source | RDS AV INPUT | AV / Input / RDS |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| EPG | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| VOL + | Vol + | VOL + | Vol + |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC |
| CH+ | CH+ | CH PAGE + | CH+ / Page+ |
| VOL - | Vol - | VOL - | Vol - |
| REC | REP/Rec | REC MODE | Rec / Rec Mode |
| CH- | CH- | CH PAGE - | CH- / Page- |
| 1 | 1 | TV 1 | 1 |

| Original | | Substitut | | Original | |
|---|---|---|---|---|---|
| 2 | 2 | DVD 2 | 2 | | |
| 3 | 3 | CD - STB 3 | 3 | | |
| 4 | 4 | VIDEO 4 | 4 | | |
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| RECALL | Recall | RETURN BACK | Back / Return | | |

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| Power | Power | TXT/MIX | Text / Goto |
| Mute | Mute / Dimmer | Menu | Menu / Home |
| Play | Play / Slow | Up | Up |
| Pause | Pause / Step / Freeze | Info | Info / Angle |
| Stop | Stop / Hold | Left | Left |
| Rec | Rec / Rec Mode | Enter | OK |
| <</Hold | << / Tune- | Right | Right |
| >>/Index | >> / Tune+ | Cancel | Exit / Cancel / Clear |
| I<< | I<< / Preset- | Down | Down |
| >>I | >>I / Preset+ | Back | Back / Return |
| Nicam/A2 | Audio / Lang I/II | Vol + | Vol + |
| Subtitle | Subtitle / EQ | List | Smart / List |
| Subpage | Eject / Surround | CH+ | CH+ / Page+ |
| Size | Zoom / Size | Vol - | Vol - |
| Sleep | Sleep / Timer | Mode | Display / Media |
| DTV/Radio | TV/Radio / | CH- | CH- / Page- |
| Reveal | D.Menu / Top | 1 | 1 |

Menu

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| 2 | DVD 2 | FAV+ | SHIFT + Right — Shift + Right |
| 3 | CD - STB 3 | -/-- | SHIFT + GUIDE EPG — Shift + Guide / EPG / -/-- |
| 4 | VIDEO 4 | | |
| 5 | TAPE 5 | | |
| 6 | TUNER 6 | | |
| 7 | AUX - HDD 7 | | |
| 8 | USB 8 | | |
| 9 | BLUETOOTH 9 | | |
| EPG | -/-- GUIDE EPG — Guide / EPG / -/-- | | |
| 0 | HDMI - SAT 0 | | |
| FAV | PC FAV MARKER — Fav / Marker / PC | | |
| Red | NETFLIX SEARCH — Red / Netflix / Search | | |
| Green | APP REPEAT — Green / APP / Repeat | | |
| Yellow | YouTube REPEAT A-B — Yellow / YouTube / Repeat | | |
| Blue | Prime Video RANDOM — Blue / Prime Video / Random | | |
| <</Hold | SHIFT + HOLD — Shift + Stop / | | |
| FAV- | SHIFT + Left — Shift + Left | | |

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| Power | Power | Up | Up |
| Mute | Mute / Dimmer | Info | Info / Angle |
| Play | Play / Slow | Left | Left |
| Pause | Pause / Step / Freeze | Ok | OK |
| Stop | Stop / Hold | Right | Right |
| Rec | Rec / Rec Mode | Exit | Exit / Cancel / Clear |
| <</[Timer] | << / Tune- | Down | Down |
| >>/[≡?] | >> / Tune+ | Recall | Back / Return |
| I<</[≡↕] | I<< / Preset- | Vol + | Vol + |
| >>I/[≡. . .] | >>I / Preset+ | [≡i] | Smart / List |
| Audio | Audio / Lang I/II | Ch+ | CH+ / Page+ |
| Subtitle | Subtitle / EQ | Vol - | Vol - |
| I<</[≡↕] | Zoom / Size | Ch- | CH- / Page- |
| <</[Timer] | Sleep / Timer | 1 | 1 |
| Text | Text / Goto | 2 | 2 |
| Source/Av | AV / Input / RDS | 3 | 3 |
| [II] | Menu / Home | 4 | 4 |

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| 5 | TAPE 5 5 | | |
| 6 | TUNER 6 6 | | |
| 7 | AUX - HDD 7 7 | | |
| 8 | USB 8 8 | | |
| 9 | BLUETOOTH 9 9 | | |
| Epg | -/-- GUIDE EPG Guide / EPG / -/-- | | |
| 0 | HDMI - SAT 0 0 | | |
| Fav | PC FAV MARKER Fav / Marker / PC | | |
| Red | NETFLIX SEARCH Red / Netflix / Search | | |
| Green | APP REPEAT Green / APP / Repeat | | |
| Yellow | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Blue | Prime Video RANDOM Blue / Prime Video / Random | | |
| Freeze | SHIFT + STEP - FREEZE Shift + Pause / Step / | | |
| | | | |
| | | | |
| | | | |
| | | | |