Original		Substitut	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
AUTO OFF	Auto Off	RETURN BACK	Back
CLOCK/ TIMER	Clock/Timer	SHIFT +	TIMER AV Shift + AV
DISPLAY	Display	DISPLAY INFO	Info
PLAY/ REC	Timer Play/Rec	APP MEDIA	Media
DIMMER	Dimmer	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Substitut	
DEL	Del	FAV PRE-CH	Pre Ch
≥10	+10	-/-- GUIDE	Guide
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
BASS/TREBLE	Bass/Treble	SEARCH TV/R	TV/R
PROGRAM	Program	SHIFT +	PROG SLEEP Shift + Sleep
CLEAR	Clear	CLEAR EXIT	Exit
PLAY MODE	Play Mode	PICTURE FORMAT	Format
REPEAT	Repeat	REPEAT TEXT	Text
CD ►/II	Play/Pause CD	A	Red
USB ►/II	Play/Pause USB	B	Green
FM/AM MUSIC P.	Music P./FM/AM	C	Yellow
OPTION ►/II	Play/Pause Option	PLAY MODE ►	Play
ALBUM ■	Stop	■	Stop
OK	OK	OK	Ok
▼	▼	CH −	Ch -

Original	Substitut	Original	Substitut
Album Down	Down		
Album Up	Up		
▲	Ch +		
>>I	>>I		
I <<	I <<		
D. Bass	Subt		
Preset EQ	AV		
Surround	Dual		
Re-Master	Shift + Media		
Rec/Pause USB	Rec		
Rec Mode	Shift + Rec		
Edit Mode	3D		