Original	Substitut	Original	Substitut
Standby AV	Power	Green	Green / APP / Repeat
Info	Info / Angle	Yellow	Yellow / YouTube / Repeat
Direct Navigator	Smart / List	Blue	Blue / Prime Video / Random
Menu	Menu / Home	Stop	Stop / Hold
EPG	Guide / EPG / -/--	Pause	Pause / Step / Freeze
Exit	Exit / Cancel / Clear	Play	Play / Slow
Edit	Fav / Marker / PC	1	1
<<	<< / Tune-	2	2
>>	>> / Tune+	3	3
Delete	Back / Return	4	4
Prog/Check	Setup / OPT /	5	5
Up	Up	6	6
Down	Down	7	7
Left	Left	8	8
Right	Right	9	9
OK	OK	0	0
Red	Red / Netflix / Search	Live	Display / Media

Original	Substitut	Original	Substitut
Tv/ Radio	TV/ Radio /		
Rec	Rec / Rec Mode		
Rec Pause	Shift + Pause / Step /		
Viewer	Zoom / Size		
Skip	AV / Input / RDS		
Set Book Mark	Subtitle / EQ		
Go Book Mark	Shift + TV/ Radio / Program		
Vol +	Vol +		
Vol -	Vol -		
Timer Rec	Sleep / Timer		
Replay	>>I / Preset +		
Audio	Audio / Lang I/II		
Aspect	Picture / Format		

Original	Substitut	Original	Substitut
Power Tv	SHIFT + Shift + Power	Up	Up
Tv/AV Tv	SHIFT + RDS AV INPUT Shift + AV / Input / RDS	Down	Down
CH+ TV	CH+ / Page+	Left	Left
CH- Tv	CH- / Page-	Right	Right
Vol + Tv	SHIFT + VOL Shift + Vol +	OK	OK
Vol - Tv	SHIFT + VOL Shift + Vol -	Red	NETFLIX SEARCH Red / Netflix / Search
Standby AV	Power	Green	APP REPEAT Green / APP / Repeat
Info	ANGLE INFO Info / Angle	Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat
Direct Navigator	LIST SMART Smart / List	Blue	Prime Video RANDOM Blue / Prime Video / Random
Menu	HOME MENU Menu / Home	Stop	HOLD Stop / Hold
EPG	-/-- GUIDE EPG Guide / EPG / -/--	Pause	STEP-FREEZE Pause / Step / Freeze
Exit	CLEAR EXIT CANCEL Exit / Cancel / Clear	Play	SLOW Play / Slow
Edit	PC FAV MARKER Fav / Marker / PC	1	TV 1 1
<<	TUNE- << / Tune-	2	DVD 2 2
>>	TUNE+ >> / Tune+	3	CD-STB 3 3
Delete	RETURN BACK Back / Return	4	VIDEO 4 4
Prog/Check	OPT-TOOLS SETUP Setup / OPT / Tools	5	TAPE 5 5

Original		Substitut		Original		Substitut	
6	6	TUNER 6	6	AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
7	7	AUX - HDD 7	7	ASPECT	Aspect	FORMAT PICTURE	Picture / Format
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
0	0	HDMI - SAT 0	0				
LIVE	Live	MEDIA DISPLAY	Display / Media				
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /				
REC	Rec	REC MODE	Rec / Rec Mode				
REC PAUSE	Rec Pause	SHIFT + STEP - FREEZE II	Shift + Pause / Step /				
VIEWER	Viewer	SIZE ZOOM	Zoom / Size				
SKIP	Skip	RDS AV INPUT	AV / Input / RDS				
BOOK SET	Set Book Mark	EQ SUBTITLE	Subtitle / EQ				
MARK GO	Go Book Mark	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program				
VOLUME	Vol +	+ VOL	Vol +				
	Vol -	VOL −	Vol -				
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer				
REPLAY	Replay	PRESET- ⏮	I << / Preset-				