Original		Substitut	
SHOW VIEW	Show View	ANGLE INFO	Info / Angle
	Up		Up
	Down		Down
CHECK	Check	PC FAV MARKER	Fav / Marker / PC
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
PDC/VPS	PDC/VPS	FORMAT PICTURE	Picture / Format
SP/LP	SP/LP	OPT-TOOLS SETUP	Setup / OPT /
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
STORE	Store	RETURN BACK	Back / Return
	<<	TUNE-	<< / Tune-
	Left		Left
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Right		Right
	Stop	HOLD	Stop / Hold

Original		Substitut	
VCR	Power VCR		Power
PAUSE/SLOW	Pause/Slow	STEP-FREEZE	Pause / Step / Freeze
REC/OTR	Rec/OTR	REC MODE	Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TRANSMIT	Transmit	LIST SMART	Smart / List
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TRACKING/V-LOCK	Tracking/V-Lock	CH PAGE	CH+ / Page+
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
SAT 0	0/SAT	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Substitut	Original	Substitut
Tracking/V-Lock Down	CH- / Page-		
Power TV	Shift + Power		
OSD	Display / Media		
Direct Tv Rec	TV/Radio /		
Tv Vol +	Vol +		
AV	Shift + AV / Input / RDS		
I<< Index	I<< / Preset-		
Index >>I	>>I / Preset+		
Tv Vol -	Vol -		

Original	Substitut	Original	Substitut
Power TV	Power	I << Index	I << / Preset-
1	1	Index >>I	>>I / Preset+
2	2	Up	CH+ / Page+
3	3	Down	CH- / Page-
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
-/--	Guide / EPG / -/--		
Vol +	Vol +		
Vol -	Vol -		
AV	AV / Input / RDS		
Direct Tv Rec	Rec / Rec Mode		
OSD	Display / Media		