Mandis shop

Pioneer CU-XC004

Original	Substitut	Original	Substitut
Direct Play (--	Red / Netflix / Search	Volume+	Vol +
Direct Play OO	Green / APP / Repeat		
Direct Play Y	Yellow / YouTube / Repeat		
Direct Play [*	Blue / Prime Video / Random		
Menu	Menu / Home		
>>	>> / Tune+		
Cancel	Exit / Cancel / Clear		
I <</-	I << / Preset-		
Stop	Stop / Hold		
>>I / +	>>I / Preset+		
Set	Setup / OPT /		
<<	<< / Tune-		
AUX	7		
Sound	Sound / Title		
Display	Display / Media		
Power	Power		
Volume-	Vol -		

https://mandis.ch/a/Pioneer/10637-39/comment-desbloquear-Pioneer-CU-XC004-AD745.htm