Mandis shop

Pioneer CU-PD046

Original		Substitut	
	Standby / On		Power
DISC 1	Disc 1	1	1
DISC 2	Disc 2	2	2
DISC 3	Disc 3	3	3
DISC 4	Disc 4	4	4
DISC 5	Disc 5	5	5
DISC 6	Disc 6	6	6
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Play		Play / Slow
RANDOM	Random		Blue / Prime Video / Random
	<<		<< / Tune-
	>>		>> / Tune+
HI-LITE	Hi-Lite		Smart / List
	I<<		I<< / Preset-
	>>I		>>I / Preset+
PROGRAM	Program		TV/Radio / Program

Original		Substitut	
DELETE	Delete		Back / Return
CHECK	Check		OK
CLEAR	Clear		Exit / Cancel / Clear

https://mandis.tv/pioneer/1076930-comment-substituer-pioneer-cu-pd104.htm