Mandis shop

Sony RM-SRM1

Original	Substitut	Original	Substitut
SLEEP Sleep	TIMER SLEEP Sleep / Timer	CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear
SELECT Clock/Timer	SHIFT + TIMER SLEEP Shift + Sleep / Timer	PLAY MODE Play Mode	SLOW ▶ Play / Slow
SET Clock/Timer Set	PROGRAM TV/RADIO TV/Radio /	REPEAT Repeat	APP REPEAT Green / APP / Repeat
I/⏻ Power	⏻ Power	ENTER Enter	OK OK
FUNCTION Function	TOP MENU D.MENU D.Menu / Top	⏮ I<<	PRESET- ⏮ I<< / Preset-
TUNER MEMORY Tuner Memory	TUNER 6 6	VOL + Vol +	+ VOL Vol +
DISPLAY Display	MEDIA DISPLAY Display / Media	⏭ >>I	PRESET+ ⏭ >>I / Preset+
TAPE Tape	TAPE 5 5	EQ- EQ-	SHIFT + VOL – Shift + Vol -
◀▶ <> Tape	SHIFT + TAPE 5 Shift + 5	EQ EQ	EQ SUBTITLE Subtitle / EQ
■ Stop Tape	SHIFT + HOLD ■ Shift + Stop /	EQ+ EQ+	SHIFT + + VOL Shift + Vol +
TUNER/BAND Tuner/Band	SHIFT + TUNER 6 Shift + 6	VOL – Vol -	VOL – Vol -
TUNING – Tuner/Band	CH PAGE – CH- / Page-	◀◀ <<	TUNE- ◀◀ << / Tune-
TUNING + Tuner/Band	+ CH PAGE CH+ / Page+	▶▶ >>	TUNE+ ▶▶ >> / Tune+
CD CD	CD-STB 3 3		
►II Play CD	SHIFT + SLOW ▶ Shift + Play /		
►II Pause CD	STEP-FREEZE II Pause / Step / Freeze		
■ Stop CD	HOLD ■ Stop / Hold		

https://mandis.tv/a/Sony/1395-231-comment-substituer-sony-rm-srm1-177511.htm