Mandis shop

Sony RM-AMU166

Original	Substitut
Power	Power
Display	INFO
Sleep	VOD
Play Mode/Tuning Mode	WIDE
Repeat/FM	TEXT
Bass Bazuca	Subt.
EQ	Audio
Tuner Memory	TV/R
Timer Menu	MENU
Return	BACK
Options	OPT+
Up	UP
Down	DOWN
Right	RIGHT
Left	LEFT
OK	OK
I<</ -	First

Original	Substitut
>>I / +	Last
<<	Rewind
>>	Fast Forward
Play	Play
Pause	Pause
Stop	Stop
Folder+	V-FOR
Folder-	SRC
Led Speaker	MEDIA
Vol +	VOL +
Vol -	VOL -
Function+	CH +
Function-	CH -