Mandis shop

Sony RMSD70S

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| Disc Skip | Eject / Surround | >> | >> / Tune+ |
| Sleep | Sleep / Timer | Play Deck B | 2 |
| Power | Power | Play Deck B | Blue / Prime Video / Random |
| Play CD | 3 | Check | Info / Angle |
| Play CD | Red / Netflix / Search | Clear | Exit / Cancel / Clear |
| Pause | Pause / Step / Freeze | Function | Menu / Home |
| Stop | Stop / Hold | Loop | Smart / List |
| Play | 6 | Flash | Display / Media |
| Play | Green / APP / Repeat | Up | Up |
| I<<- | I<< / Preset- | Vol + | Vol + |
| I<<- | CH- / Page- | Left | Left |
| >>I+ | CH+ / Page+ | On/Off | OK |
| >>I+ | >>I / Preset+ | Right | Right |
| Play Deck A | 1 | Down | Down |
| Play Deck A | Yellow / YouTube / Repeat | Vol - | Vol - |
| Play Deck A | 5 | | |
| << | << / Tune- | | |

https://mandis.tv/c/Sony/1074-303-control-de-substitucion-Sony-RMSD70S.htm