Mandis shop

Sony RM-DX153

Original		Substitut	
DISC	Disc		Left
TRACK	Track		Up
GROUP	Group		Right
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
10/0 0	10/0	HDMI-SAT 0	0
ENTER	Enter	OK	OK
CONTINUE	Continue	NETFLIX SEARCH	Red / Netflix / Search
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random

Original		Substitut	
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
MEMO SCAN	Memo Scan	LIST SMART	Smart / List
DISPLAY	Display	MEDIA DISPLAY	Display / Media
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
AMS	I<< AMS	PRESET-	I<< / Preset-
AMS	AMS >>I	PRESET+	>>I / Preset+
DISC SKIP +	Disc Skip +	CH PAGE +	CH+ / Page+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
DISC SKIP −	Disc Skip -	CH PAGE −	CH- / Page-