# Mandis shop

RCTMB100

| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| | Green/Timer/List | APP / REPEAT | Green / APP / Repeat |
| | Yellow/Info | YouTube / REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue/[^] | Prime Video / RANDOM | Blue / Prime Video / Random |
| | Red/[o] | NETFLIX / SEARCH | Red / Netflix / Search |
| | Up | | Up |
| | Violet/Text | GOTO TEXT | Text / Goto |
| | Left | | Left |
| | OK | OK | OK |
| | Right | | Right |
| | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Menu | HOME MENU | Menu / Home |
| | Vol + | VOL + | Vol + |
| | Down | | Down |
| | PR+ | CH PAGE + | CH+ / Page+ |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Vol - | VOL – | Vol - |

| Original | | Substitut | |
|---|---|---|---|
| | PR- | CH PAGE – | CH- / Page- |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| av | AV | RDS AV INPUT | AV / Input / RDS |
| 0/-- | 0/-- | HDMI-SAT 0 | 0 |

https://mandis.tv/a/1063-2264-comment-de-substituer-RCTMB100-28920.htm