| Original | Substitut | Original | Substitut |
|---|---|---|---|
| Power Source | SHIFT + Power | USB | SHIFT + 8 |
| Power Receiver | Power | NET | SHIFT + 0 |
| HDMI 1 | SHIFT + 1 | PHONO | SHIFT + 9 |
| HDMI 2 | SHIFT + 2 | PARTY | AV / Input / RDS |
| HDMI 3 | SHIFT + 3 | HDMI OUT | Smart / List |
| HDMI 4 | SHIFT + 4 | Scene BD/DVD | Red / Netflix / Search |
| HDMI 5 | SHIFT + 5 | Scene TV | Green / APP / Repeat |
| V-AUX | SHIFT + 7 | Scene NET | Yellow / YouTube / Repeat |
| AV 1 | SHIFT + Shift + Red / Netflix / | Scene Radio | Blue / Prime Video / Random |
| AV 2 | SHIFT + Shift + Green / APP / | Program Up | CH+ / Page+ |
| AV 3 | SHIFT + Shift + Yellow / YouTube / | Vol + | Vol + |
| AV 4 | SHIFT + Shift + Blue / Prime | Program Down | CH- / Page- |
| AV 5 | SHIFT + Shift + Guide / EPG / -/-- | Vol - | Vol - |
| AV 6 | SHIFT + Shift + Fav / Marker / PC | Top Menu | D.Menu / Top |
| Audio 1 | Sound / Title | Pop-Up/Menu | Menu / Home |
| Audio 2 | Audio / Lang I/II | On Screen | Text / Goto |
| Tuner | SHIFT + 6 | Up | Up |

| Original | | Substitut | |
|---|---|---|---|
| OPTION | Option | OPT-TOOLS SETUP | Setup / OPT / |
| ◀ | Left | ◀ | Left |
| ENTER | Enter | OK | OK |
| ▶ | Right | ▶ | Right |
| RETURN | Return | RETURN BACK | Back / Return |
| ▼ | Down | ▼ | Down |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| MODE | Mode | SHIFT + OK | Shift + OK |
| ■ | Stop | HOLD ■ | Stop / Hold |
| ❚❚ | Pause | STEP-FREEZE ❚❚ | Pause / Step / Freeze |
| BAND ► | Play/Band | SLOW ▶ | Play / Slow |
| TUN ◄◄ | << Tuning | TUNE- ◄◄ | << / Tune- |
| JING ►► | Tuning >> | TUNE+ ►► | >> / Tune+ |
| PRE ►◄ | I<< Preset | PRESET- ►◄ | I<< / Preset- |
| ESET ►►I | Preset >>I | PRESET+ ►►I | >>I / Preset+ |
| MOVIE | Movie | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| MUSIC | Music | SHIFT + LIST SMART | Shift + Smart / List |

| Original | | Substitut | |
|---|---|---|---|
| SUR. DECODE | Sur. Decode | SURROUND ⏏ | Eject / Surround |
| STRAIGHT | Straight | EQ SUBTITLE | Subtitle / EQ |
| INFO | Info | ANGLE INFO | Info / Angle |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| ENHANCER | Enhancer | FORMAT PICTURE | Picture / Format |
| PURE DIRECT | Pure Direct | SIZE ZOOM | Zoom / Size |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| MEMORY +10 | +10/Memory | -/-- GUIDE EPG | Guide / EPG / -/-- |

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| ENT | Fav / Marker / PC | | |
| Mute | Mute / Dimmer | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substitut | |
|---|---|---|---|
| | Power Source | SHIFT + | Shift + Power |
| | Power Receiver | | Power |
| 1 | HDMI 1 | SHIFT + TV 1 | Shift + 1 |
| 2 | HDMI 2 | SHIFT + DVD 2 | Shift + 2 |
| 3 | HDMI 3 | SHIFT + CD-STB 3 | Shift + 3 |
| 4 | HDMI 4 | SHIFT + VIDEO 4 | Shift + 4 |
| 5 | HDMI 5 | SHIFT + TAPE 5 | Shift + 5 |
| V-AUX | V-AUX | SHIFT + AUX-HDD 7 | Shift + 7 |
| 1 | AV 1 | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| 2 | AV 2 | SHIFT + APP REPEAT | Shift + Green / APP / |
| 3 | AV 3 | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| 4 | AV 4 | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| 5 | AV 5 | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| 6 | AV 6 | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| 1 | Audio 1 | TITLE SOUND | Sound / Title |
| 2 | Audio 2 | LANG I/II AUDIO | Audio / Lang I/II |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |

| Original | | Substitut | |
|---|---|---|---|
| USB | USB | SHIFT + USB 8 | Shift + 8 |
| NET | NET | SHIFT + HDMI-SAT 0 | Shift + 0 |
| PHONO | Phono | SHIFT + BLUETOOTH 9 | Shift + 9 |
| PARTY | Party | RDS AV INPUT | AV / Input / RDS |
| HDMI OUT | HDMI Out | LIST SMART | Smart / List |
| BD DVD | Scene BD/DVD | NETFLIX SEARCH | Red / Netflix / Search |
| TV | Scene TV | APP REPEAT | Green / APP / Repeat |
| NET | Scene NET | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| RADIO | Scene Radio | Prime Video RANDOM | Blue / Prime Video / Random |
| + VOLUME | Vol + | + VOL | Vol + |
| VOLUME — | Vol - | VOL — | Vol - |
| TOP MENU | Top Menu | TOP MENU D.MENU | D.Menu / Top |
| POP-UP/MENU | Pop-Up/Menu | HOME MENU | Menu / Home |
| ON SCREEN | On Screen | GOTO TEXT | Text / Goto |
| ▲ | Up | ▲ | Up |
| OPTION | Option | OPT-TOOLS SETUP | Setup / OPT / |
| ◀ | Left | ◀ | Left |

| Original | | Substitut | |
|---|---|---|---|
| ENTER | Enter | OK | OK |
| ▶ | Right | ▶ | Right |
| RETURN | Return | RETURN BACK | Back / Return |
| ▼ | Down | ▼ | Down |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| MODE | Mode | SHIFT + OK | Shift + OK |
| ■ | Stop | HOLD ■ | Stop / Hold |
| ❚❚ | Pause | STEP-FREEZE ❚❚ | Pause / Step / Freeze |
| BAND ▶ | Play/Band | SLOW ▶ | Play / Slow |
| TUN ◀◀ | << Tuning | TUNE- ◀◀ | << / Tune- |
| JING ▶▶ | Tuning >> | TUNE+ ▶▶ | >> / Tune+ |
| PRE ⏮ | I<< Preset | PRESET- ⏮ | I<< / Preset- |
| ESET ⏭ | Preset >>I | PRESET+ ⏭ | >>I / Preset+ |
| INFO | Info | ANGLE INFO | Info / Angle |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |

| Original | | Substitut | |
|---|---|---|---|
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| MEMORY +10 | +10/Memory | -/-- GUIDE EPG | Guide / EPG / -/-- |
| ENT | ENT | PC FAV MARKER | Fav / Marker / PC |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |