Mandis shop

Yamaha RAS13

Original	Substitut	Original	Substitut
Power AMP	Power	Preset >	Right
Open/Close	Eject	<<	<<
Power CD	SHIFT + Shift + Power	Disc Skip	Smart
Pure Direct	Guide	>>	>>
Coaxial	4	Pause	Pause
Optical	5	Stop	Stop
Line 1	1	Play	Play
Line 2	2	>>I	>>I
Line 3	3	I <<	I <<
Tuner	6	Vol +	Vol +
Phono	7	Vol -	Vol -
CD	8	Mute	Mute
Band	Up		
<< Tuning	Ch -		
Tuning >>	Ch +		
Memory	Ok		
< Preset	Left		

https://mandis.ca/ca/Yamaha/10674-6818-comment-de-substituer-pour-Yamaha-RAS13-ZN04290.html