







































































Original	Substitut	Original	Substitut
 Power	 Power	 CH+	 Ch +
 Source	 AV	 CH-	 Ch -
 Sleep	 Sleep	 Down	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Vol-	 Vol -
 3	 3	 Vol+	 Vol +
 4	 4	 Enter	 Ok
 5	 5	 Red	 Red
 6	 6	 Green	 Green
 7	 7	 Yellow	 Yellow
 8	 8	 Blue	 Blue
 9	 9	 Info	 Info
 0	 0	 EPG	 Guide
 -/--	 SHIFT + -/-- Guide	 Menu	 Menu
 Recall	 Pre Ch	 Nicam	 Media
 Up	 Up	 FAV+	 >>





	Original	Substitut		
	FAV-		<<	
	TXT		Text	
	Edit/Group		Options	
	Index		Back	
	Lang/Audio		Dual	
	TV/Radio		TV/R	
	Subtitle		Subt	
	Subpage		Shift + Subt	
	Size		Format	
	Hold		3D	
	Still		Exit	
	P.Mode		Shift + Format	
	S.Mode		Shift + Dual	

	Original	Substitut		

